

User station

**WB-2P-LR2**

User manual

Firmware version 2.6.0

IP address: 192.168.1.1

Username: admin

Password: password

## Contents

<b>1</b>	<b>Introduction .....</b>	<b>5</b>
1.1	Annotation.....	5
1.2	Symbols .....	5
<b>2</b>	<b>Device description.....</b>	<b>6</b>
2.1	Purpose.....	6
2.2	Device specification .....	6
2.3	Technical features.....	8
2.4	Design .....	10
2.5	Light indication .....	11
2.6	Reset to the default settings.....	12
2.7	Delivery package .....	12
<b>3</b>	<b>Installation order .....</b>	<b>13</b>
3.1	Safety rules.....	13
3.2	Installation recommendations.....	13
3.3	Recommendations for lightning protection .....	14
3.4	WB-2P-LR2 mounting.....	15
3.4.1	Pre-tuning.....	15
3.4.2	Mounting order .....	15
3.4.3	Mounting the device using a bracket .....	17
3.4.4	Bracket dimensions .....	17
3.5	Switching on.....	17
<b>4</b>	<b>Managing the device through web configurator .....</b>	<b>18</b>
4.1	Getting started .....	18
4.2	Changing user.....	19
4.3	Applying configuration and discarding changes.....	20
4.4	Test changes mode .....	21
<b>5</b>	<b>Main elements of the web interface .....</b>	<b>22</b>
5.1	The 'Monitoring' menu .....	23
5.1.1	The 'Internet' submenu .....	23
5.1.2	The 'WDS' submenu .....	24
5.1.3	The 'Ethernet ports' submenu.....	25
5.1.4	The 'DHCP' submenu .....	26
5.1.5	The 'ARP' submenu .....	26
5.1.6	The 'PPPoE Relay' submenu.....	27

5.1.7	The 'PPPoE Client' submenu .....	27
5.1.8	The 'Device info' submenu .....	28
5.1.9	The 'Contrack' submenu .....	29
5.1.10	The 'Routes' submenu .....	30
5.2	The 'Network' menu .....	31
5.2.1	The 'Internet' submenu .....	31
5.2.2	The 'Radio' submenu .....	41
5.2.3	The 'LAN' submenu .....	43
5.2.4	The 'MAC Management' submenu.....	44
5.2.5	The 'Local DNS' submenu.....	45
5.2.6	The 'NAT and Port Forwarding' submenu .....	46
5.2.7	The 'Firewall' submenu .....	47
5.2.8	The 'Routes' submenu .....	49
5.2.9	The 'Dynamic DNS' submenu .....	50
5.2.10	The 'SNMP' submenu .....	51
5.3	The 'IPTV' menu .....	52
5.3.1	The 'IPTV' submenu .....	52
5.4	The 'System' menu .....	53
5.4.1	The 'Time' submenu .....	53
5.4.2	The 'Access' submenu.....	54
5.4.3	The 'Log' submenu.....	55
5.4.4	The 'Passwords' submenu.....	57
5.4.5	The 'Configuration management' submenu .....	58
5.4.6	The 'Firmware Upgrade' submenu .....	59
5.4.7	The 'Reboot' submenu.....	60
5.4.8	The 'Autoprovisioning' submenu .....	60
5.4.9	The 'Advanced' submenu .....	63
<b>6</b>	<b>Configuration example .....</b>	<b>64</b>
<b>7</b>	<b>Limiting the number of MAC addresses learned (mac-learning limit) .....</b>	<b>66</b>
<b>8</b>	<b>Spectrum Analyzer .....</b>	<b>67</b>
<b>9</b>	<b>Automatic DHCP-based update algorithm.....</b>	<b>68</b>
<b>10</b>	<b>System recovering after firmware update failure .....</b>	<b>71</b>
<b>11</b>	<b>Appendix A. Launch user script when starting the system.....</b>	<b>72</b>
<b>12</b>	<b>Application B. Antenna patterns .....</b>	<b>73</b>
<b>13</b>	<b>The list of changes.....</b>	<b>74</b>



# 1 Introduction

## 1.1 Annotation

Modern tendencies of telecommunication development necessitate operators to search for the most optimal technologies, allowing you to satisfy drastically growing needs of subscribers, maintaining at the same time consistency of business processes, development flexibility and reduction of costs of various services provision. Wireless technologies are spinning up more and more and have paced a huge way for a short time from unstable low-speed communication networks of low radius to broadband networks equitable to speed of wired networks with high criteria for the quality of provided services.

WB-2P-LR2 is a user station designed for connection to Wi-Fi access network which might be constructed using base stations within long distances. The case of WB-2P-LR2 is sealed, that is allows to install the device outdoor with different climate conditions.

This manual specifies intended purpose, main technical parameters, design, installation procedure, safe operation rules and installation recommendations for WB-2P-LR2.

## 1.2 Symbols

### Notes and warnings

 **Notes contain important information, tips or recommendations on device operation and setup.**

 **Warnings are used to inform the user about harmful situations for the device and the user alike, which could cause malfunction or data loss.**

## 2 Device description

### 2.1 Purpose

User station WB-2P-LR2 (herein after 'the device') is designed for access provision to secure wireless network.

WB-2P-LR2 connects to a base station via Wi-Fi technology and operates at 2.4 GHz (the frequency range – 2402–2482 MHz). The device is supposed to operate with WOP-2ac-LR2. WB-2P-LR2 might be also used for wireless bridge organization.

WB-2P-LR2 supports up-to-date requirements to service quality and allows transmitting more important traffic in higher priorities queues. Prioritization is based on QoS technologies: CoS (special tags in VLAN packet field) and ToS (tags in IP packet field).

The device is capable to operate in wide temperature range and in high-humidity conditions (parks, factories, stadiums, etc.).

Power to the device is supplied via Passive PoE technology 24V.

### 2.2 Device specification

#### **Interfaces:**

- 1 port of Ethernet 10/100/1000BASE-T (RJ-45);
- Wi-Fi 2.4 GHz IEEE 802.11b/g/n.

The power is supplied via PoE injector 24V connected to 220V network.


 **Use of injector with voltage different from 24V will cause the device failure!**

#### **Network functions:**


- operating in bridge and router modes;
- operating in 'Wi-Fi Station' and 'Wireless bridge' modes;
- support for VLAN Trunk;
- support for Management VLAN;
- support for General VLAN;
- support for Transparent Mode;
- support for VLAN Mapping;
- static routing;
- support for Transparent wireless bridge function;
- support for PPPoE client;
- time synchronization via NTP;
- support for static address and DHCP (DHCP client on WAN side, DHCP server on LAN side);
- support for DNS;
- support for D-DNS;
- support for NAT;
- support for UPnP;
- firewall;
- support for cloning of MAC address on WAN interface;
- support for quality of service mechanisms (QoS through DSCP and 802.1P).
- support for IPTV functions (IGMP-proxy, UDP-to-HTTP proxy);
- support for MVR;
- support for limiting the number of MAC addresses learned (MAC-learning);
- firmware update via web interface;
- support for DHCP-based autoprovisioning;

- support for TR-069;
- remote monitoring, configuration and setup: SNMP, web interface, Telnet, SSH.


The figures below illustrate applications schemes of WB-2P-LR2.



Functional scheme of using WB-2P-LR2 without router



Functional scheme of using WB-2P-LR2 with router



Functional scheme of using WB-2P-LR2 for wireless bridge organization

## 2.3 Technical features

Table 1 shows main specifications of the device.

Table 1 – Main specifications

<b>LAN Ethernet interface parameters</b>	
Number of ports	1
Electrical connector	RJ-45
Data rate, Mbps	10/100/1000, auto-negotiation
Standards	BASE-T
<b>Wireless interface parameters</b>	
Standards	802.11b/g/n
Frequency range	2402–2482 MHz
Modulation	DSSS, CCK, BPSK, QPSK, 16QAM, 64QAM
Speed of data transmission	<b>802.11b:</b> up to 11 Mbps <b>802.11g:</b> up to 54 Mbps <b>802.11n:</b> up to 300 Mbps
Maximum output power of the transmitter	<b>2.4 GHz:</b> 26 dBm
Receiver sensitivity	<b>2.4 GHz:</b> -98 dBm
Security	64/128/152-bit WEP encryption, WPA/WPA2, centralized authorization via RADIUS server (WPA/WPA2 Enterprise)
<b>Antenna parameters</b>	
Gain	2x10.5 dBi
Polarization	dual-polarized antenna
Beam angle (horizontal polarization)	60°

Beam angle (horizontal polarization)	40°
SWR	2.0 max
Impedance	50 Ohm
Front to back ratio	> 20 dB
<b>Control</b>	
Remote control	web interface, Telnet, SSH, SNMP (monitoring), TR-069
Access restriction	by password
<b>General parameters</b>	
RAM	128 MB
Flash	32 MB
Power supply	Passive PoE 24 V
Power consumption	9 W max
Operating temperatures	from -45 to +65°C
Operating humidity	95% max
Ingress Protection Rating	IP54
Dimensions (WxHxD)	80x282x66 mm
Weight	0,35 kg

## 2.4 Design


WB-2P-LR2 housed in a plastic case, industrial version. The size of the device: 80x282x66 mm.

The layout of WB-2P-LR2 is shown in the figure below.



WB-2P-LR2 layout

LAN port 10/100/1000BASE-T (RJ-45 connector) for local network connection and power supply via PoE, grounding connector and the button for resetting to factory settings ('Reset') are located on the bottom panel of the device.



WB-2P-LR2 bottom panel's elements

## 2.5 Light indication

The light indication panel of WB-2P-LR2 is shown below.



WB-2P-LR2 light indication panel

The current state of the device is shown with the help of light indicators located on the back panel of WB-2P-LR2. The list of indicators and their description is shown in the table below.

Table 2 – Description of rear panel LED indicators

	LED	LED status	Description
	<b>Power</b> – Device power and operation status LED	solid green	the device power supply is enabled, normal operation
		solid orange	the device is loaded but IP address is not received via DHCP
		solid red	the device is loading
	<b>LAN</b> – LAN interface indicator	solid green (10, 100 Mbps)/solid orange (1000 Mbps)	the channel between LAN interface of WB-2P-LR2 and connected device is active
		flashes	packet data transmission between LAN interface of WB-2P-LR2 and connected device

	LED	LED status	Description
	<b>WLAN</b> – received signal strength indicator (RSSI)	solid red	the device is connected to a base station. The base station signal level is more than -98 dBm
		solid yellow	the device is connected to a base station. The base station signal level is more than -80 dBm
		solid green	the device is connected to a base station. The base station signal level is more than -70 dBm
		solid green	the device is connected to a base station. The base station signal level is more than -60 dBm
		none of the indicators is on	the device is not connected to the base station

## 2.6 Reset to the default settings

There are two ways to reset the device to factory settings:

1. Using 'Reset' button on the device. When the device is loaded, press and hold 'Reset' button located on the bottom panel (approximately 10–15 seconds) until 'Power' indicator is flashing orange.
2. Using PoE injector supplied with the device. When the device is loaded, press and hold 'RST' button of the injector (approximately 10–15 seconds) until 'Power' indicator of WB-2P-LR2 is flashing orange.

Device will be rebooted automatically. DHCP client will be launched by default. If the address is not received via DHCP the device will have IP address – *192.168.1.1*, subnet mask – *255.255.255.0*; User Name/Password to access via Web interface: *admin/password*.

## 2.7 Delivery package

The basic supply package of WB-2P-LR2 includes:

- User station WB-2P-LR2;
- Mounting kit: 2 clamps for attaching;
- PoE injector 24 V;
- Patch cord RJ-45, 5e cat. 1.5 m;
- Cord for europlug – C13-F-1.8 m;
- Sheet with light indication description;
- Conformity certificate;
- Technical passport.

A bracket with horizontal and vertical adjustment might be included to the supply package upon a request.

## 3 Installation order

This section defines safety rules, installation recommendations, setup procedure and the device starting procedure.

### 3.1 Safety rules

1. Do not open the device case. There are no user serviceable parts inside.
2. Do not install the device during a thunderstorm. There is a risk of lightning stroke.
3. You must follow requirements for voltage, current and frequency specified in the user manual.
4. Measuring devices and computer must be grounded before connecting to the device. The electric potential difference between devices' cases should not exceed 1 V.
5. Make sure that all the cables are intact and they are reliably attached to connectors.
6. You should satisfy established standards and requirements for working at height during the device installation on the high-rise constructions.
7. The device exploitation should be performed by specially prepared engineering and technical personnel.
8. Connect only to operational service equipment.

### 3.2 Installation recommendations


1. Recommended location for device installation: communications mast/pole.
2. Before you install and enable device, check the device for visible mechanical defects. If defects are observed, you should stop the device installation, draw up corresponding act and contact the supplier.
3. Install the device vertically on communications mast or pole in the way that the LAN port is pointed down.
4. In order to provide better receiving signal level, the sectoral antenna of a base station should be in line of sight of WB-2P-LR2. You can achieve the highest signal level by antenna alignment with the help of RSSI indicators.
5. The transmitting part of the device is located on the other side from brackets. This area should be directed to base station sectoral antenna.

After adjusting, make sure that level of the received signal from the base station should be no more than  $-65 \div -70$  dBm.

- ✔ **Install the device on communications mast/pole so that the device is directed to base station sectoral antenna as much as possible. There should also be direct visibility to the base station.**

### 3.3 Recommendations for lightning protection

1. The grounding shall be made with insulated stranded wire. The grounding device and the cross-section of the grounding wire must comply with the requirements of the Electrical Code of Practice.
2. The first outdoor lightning protection should be installed as close as possible to the base station, connecting them with a short outdoor FTP cable with shielded connectors.
3. The second outdoor lightning protection should be installed as close as possible to the PoE switch (PoE injector), connecting them with a short outdoor FTP cable with shielded connectors.
4. The lightning protectors are connected to each other by an outdoor FTP cable up to 100 m long.
5. It is necessary to ground the base station (for more information, see [Mounting the device](#)).
6. The PoE switch (PoE injector) must be connected to a 220V electrical outlet with ground or grounded through the housing.



Wiring diagram of the subscriber station to provide lightning protection

## 3.4 WB-2P-LR2 mounting

### 3.4.1 Pre-tuning

Before installing, proceed pre-tuning of the device (see section [Configuration example](#)). For this, power on the device (paragraph 2-7, section [Mounting algorithm](#)) and follow the instructions given in the section [Configuration example](#). Make sure that the user station connects required wireless network: RSSI indicators should be on.

### 3.4.2 Mounting order

1. Install the device on communications mast/pole pointing LAN port down as it is shown on the figure below. Attach the device using clamps supplied in the device package. Comply the safety rules and recommendations given in [Safety rules](#) and [Installation recommendations](#).



2. Remove the bottom cover which close LAN-port. Ground the device through a grounding connector.



3. Connect Ethernet cable to LAN port.



4. Close the bottom cover.
5. Connect Ethernet cable connected to WB-2P-LR2 to PoE port of injector.



6. Connect Ethernet cable of your LAN network or PC to LAN port of PoE injector.




7. Connect PoE injector to 220V socket with the help of power line cord.




8. Align the position of the device for best signal level receiving. The level of received signal is shown by the indication located on the back panel of the device.
9. Fasten the clamps.

### 3.4.3 Mounting the device using a bracket

1. Attach the bracket to the desired surface.
2. Fasten the device (1) to the bracket (2) and lock it with the clamps (3) as shown in the figure below.



### 3.4.4 Bracket dimensions



### 3.5 Switching on

1. Plug the injector into 220 V outlet. Connect a PC to LAN port of the injector.
2. WB-2P-LR2 loads in a minute after switching on. Connect to the web configurator of WB-2P-LR2 through a browser.

✔ **IP address by default: 192.168.1.1.**  
**Login: *admin*, password: *password*.**

3. Network configuration is described in section [5.1 The 'Network' menu](#).

## 4 Managing the device through web configurator

### 4.1 Getting started

To start, you need to connect the device through a browser:

1. Open a web browser (web-page explorer), for example, Firefox, Opera, Chrome.
2. Enter IP-address of the device to the browser address line.

✔ **IP address by default: 192.168.1.1, subnet mask: 255.255.255.0. The device is capable to obtain an IP address via DHCP.**

If connection is successful, request form with user name and password will be displayed on a browser window.

Login:

Password:

[✔ Log In](#)

✔ **Factory settings: login: *admin*, password: *password*.**


3. Enter your username into 'Login' and password into 'Password' field. Click the 'Log in' button. Device Web configurator home page will be opened in the browser window.

The screenshot shows the web configurator interface for the ELTEX WB-2P-LR2 device. The top navigation bar includes 'Monitoring', 'Network', and 'System'. Under 'Network', there are sub-menus for 'Internet', 'Ethernet Ports', 'ARP', 'PPPoE Relay', 'Device', 'Conntrack', and 'Routes'. The 'Internet' menu is selected, displaying the 'Internet Connection' status. The status is as follows:

Network Connection	Wi-Fi Client
Connection Status	Authenticated
SSID	WOP-2ac-LR2
Access Protocol	DHCP
IP Address	100.110.0.243
Link Capacity	31
Link Quality	69 (not changed)
Link Quality Common	69
RSSI Vertical/Horizontal	-42/-39 dBm
SNR	48/53 dB
TxRate	39 Mbit/s
RxRate	117 Mbit/s

At the bottom of the status area, there is a 'Refresh' button.

- ✓ You can select languages on the top-right of the page. Russian and English languages are available for WB-2P-LR2.



The screenshot shows the top navigation bar of the WB-2P-LR2 web interface. The language selection dropdown menu is highlighted with a blue circle and an arrow pointing to it. The dropdown menu is currently set to 'EN'.

Internet Connection	
Network Connection	Wi-Fi Client
Connection Status	Authenticated
SSID	WOP-2ac-LR2
Access Protocol	DHCP
IP Address	100.110.0.243
Link Capacity	31
Link Quality	69 (not changed)
Link Quality Common	69
RSSI Vertical/Horizontal	-42/-39 dBm
SNR	48/53 dB
TxRate	39 Mbit/s
RxRate	117 Mbit/s

## 4.2 Changing user

There are two user types for the device: **admin** and **viewer**:

- **admin** (password by default: **password**) has the full access to the device: read/write any settings, full device status monitoring.
- **viewer** can only view full device configuration without editing privileges; can access full device status monitoring.



The screenshot shows the top navigation bar of the WB-2P-LR2 web interface. The 'Logout' button is highlighted with a blue circle and an arrow pointing to it.

When you click the 'Logout' button, the current user session will be terminated; login window will be displayed:

Login:

Password:

To change the access, you should specify the corresponding username and password and click the 'Log in' button.

## 4.3 Applying configuration and discarding changes

### 1. Applying configuration

- ✔ **Click 'Apply' to save configuration to flash memory and apply new settings. All the settings come into operation without device rebooting.**

The visual indication of the settings applying is realized in the web interface.

The visual indication of the settings applying:

Image	State description
	After clicking 'Apply', the process of settings saving to device memory is launched. This is indicated by the  icon in the tab name and on the 'Apply' button.
	Successful settings saving and application are indicated by the  icon in the tab name.
	If any parameter value have been set incorrectly, the error notification with description will be displayed after clicking 'Apply' button. The  mark will be displayed next to the tab name and on 'Apply' button.

The 'Apply' button in the menu appears as follows:



### 2. Discarding changes

- ✔ **You can discard changes only before clicking the 'Apply' button. If you click the 'Apply' button, all the changed parameters will be applied and saved to device memory. You will not be able to return to previous configuration after clicking 'Apply'.**

The button for discarding changes appears as follows:



## 4.4 Test changes mode

The device has a test mode for a test configuration application.

To activate it, click the 'Test changes' button on the top panel of the web interface.




Test mode operating time is 300 seconds (5 minutes). During this time you can navigate through the web configuration tabs and make any changes by applying them on each page using the 'Apply' button.



After checking the required configuration, click the 'Exit from Test Mode' button and select the desired action:


- 'Save and exit' – clicking this button will exit the test mode and save to the non-volatile memory all configuration changes that were made and applied in this mode. It will be impossible to undo changes made in the test mode.
- 'Cancel and exit' – clicking will exit the test mode and cancel all changes made in this mode. The configuration in effect on the device before the test mode is activated will be restored.

If the administrator does not exit the test mode within 300 seconds, this will happen automatically along with a rollback of all changes that have been made in this mode. After the specified time, the configuration will be restored even if access to the device is lost as a result of the changes made.



## 5 Main elements of the web interface

The figure below shows navigation elements of the web configuration.



The user interface is divided into seven areas:

1. Username, which was used to enter the system and 'Logout' button to finish the user session.
2. Menu tabs which contain submenu tabs are divided into categories: **Monitoring, Network, IPTV, System**.
3. Submenu tabs manage the settings field below.
4. Settings field, which is based on the user select. The field is dedicated to view device settings and setting configuration data.
5. Configuration management buttons, the detailed description is given in section [Applying configuration and discarding changes](#).
6. Information field. The field contain information on firmware version and web interface version.


## 5.1 The 'Monitoring' menu

To move to monitoring mode, select 'Monitoring' on the left panel.

✔ **Some pages are not updated automatically. To obtain current information from the device, click the  button.**

### 5.1.1 The 'Internet' submenu

In the Internet submenu, you can view main network settings of the device.



The screenshot shows the web interface for the ELTEX WB-2P-LR2 device. The top navigation bar includes 'Monitoring', 'Network', 'IPTV', and 'System'. Under 'Monitoring', there is a sub-menu with 'Internet', 'Ethernet Ports', 'DHCP', 'ARP', 'PPPoE Client', 'Device', 'Conntrack', and 'Routes'. The 'Internet' sub-menu is selected, displaying the 'Internet Connection' settings. A 'Refresh' button is located at the bottom of the settings table.

Internet Connection	
Network Connection	Wi-Fi Client
Connection Status	Authenticated
SSID	WOP-2ac-LR2
Access Protocol	DHCP
IP Address	100.110.0.243
Link Capacity	46
Link Quality	64
Link Quality Common	56
RSSI Vertical/Horizontal	-40/-38 dBm
SNR	32/34 dB
TxRate	39 Mbit/s
RxRate	78 Mbit/s

#### Internet Connection

- *Network connection* – the parameter shows the type of connection to external network;
- *Connection Status* – the parameter shows state of connection to external network;
- *SSID* – a name of wireless network, to which the device is connected;
- *Access Protocol* – protocol, used for network access;
- *IP address* – device IP address in external network;
- *Link Capacity* – parameter that reflects the effectiveness of the use of a modulation by the device on the transmission. It is calculated based on the number of packets transmitted on each modulation, and the reduction factors. The maximum value is 100% (means that all packets are transmitted at maximum modulation for the maximum nss type supported by the device). The minimum value is 2% (in the case when the packets are transmitted to the modulation nss1mcs0 for the device with MIMO 3x3 support). The parameter value is calculated for the last 10 s;
- *Link Quality* – parameter that displays the status of the link, calculated based on the number of sent retransmit packets. The maximum value is 100% (all transmitted packets were sent on the first attempt), the minimum value is 0% (no packets were successfully sent). The parameter value is calculated for the last 10 s;

- *Link Quality Common* – parameter that displays the status of the link, calculated based on the number of sent retransmit packets. The maximum value is 100% (all transmitted packets were sent on the first attempt), the minimum value is 0% (no packets were successfully sent). The parameter value is calculated for the entire connection time;
- *RSSI Vertical/Horizontal* – level of signal received from base station, dBm;
- *SNR* – signal/noise ratio, dB;
- *TxRate* – data rate of transmission, Mbps;
- *RxRate* – data receive rate, Mbps.

Click 'Refresh' button to update the page.

### 5.1.2 The 'WDS' submenu

✓ **The 'WDS' submenu is available only in the 'Wireless bridge' mode.**

You can view radio interface settings and wireless bridge state in the WDS submenu

Monitoring		Network	System							
Internet	WDS	Ethernet Ports	ARP	Device	Conntrack	Routes				
Radio										
Channel	1									
Channel Bandwidth	20 MHz									
Network Mode	80211bgn									
WDS										
MAC	Client Name	IP Address	Link Capacity	Link Quality	Link Quality Common	RSSI	SNR	Uptime	TxRate	RxRate
E0:D9:E3:49:C1:80	WB-2P-LR2	10.24.80.74	30	73	56	-63	21	3 min 40 s	58.5 Mbit/s	39.0 Mbit/s

#### Radio:

- *Channel* – a channel of wireless bridge;
- *Channel Bandwidth* – channel bandwidth used for wireless bridge;
- *Network mode* – the current network mode of the radio interface.

#### WDS:

- *MAC address* – MAC address of the opposite device;
- *Client Name* – network name of the opposite device;
- *IP address* – IP address of the opposite device;
- *Link Capacity* – parameter that reflects the effectiveness of the use of a modulation by the device on the transmission. It is calculated based on the number of packets transmitted on each modulation, and the reduction factors. The maximum value is 100% (means that all packets are transmitted at maximum modulation for the maximum nss type supported by the device). The minimum value is 2% (in the case when the packets are transmitted to the modulation nss1mcs0 for the device with MIMO 3x3 support). The parameter value is calculated for the last 10 s;
- *Link Quality* – parameter that displays the status of the link, calculated based on the number of sent retransmit packets. The maximum value is 100% (all transmitted packets were sent on the first attempt), the minimum value is 0% (no packets were successfully sent). The parameter value is calculated for the last 10 s;
- *Link Quality Common* – parameter that displays the status of the link, calculated based on the number of sent retransmit packets. The maximum value is 100% (all transmitted packets were sent on the first

attempt), the minimum value is 0% (no packets were successfully sent). The parameter value is calculated for the entire connection time;

- *RSSI* – level of signal received from the opposite device, dBm;
- *SNR* – signal/noise ratio, dB;
- *Uptime* – time of wireless bridge operation;
- *TxRate* – channel data rate of transmission, Mbps;
- *RxRate* – channel data rate of receiving, Mbps.

### 5.1.3 The 'Ethernet ports' submenu

You can view Ethernet ports' state in the Ethernet Ports submenu.

The screenshot shows a web interface with a navigation bar at the top containing 'Monitoring', 'Network', 'IPTV', and 'System'. Under 'Monitoring', there are sub-menus: 'Internet', 'Ethernet Ports', 'DHCP', 'ARP', 'PPPoE Client', 'Device', 'Conntrack', and 'Routes'. The 'Ethernet Ports' submenu is active, displaying a table titled 'State' with the following data:

Port	Connection	Speed	Mode	Transmitted	Received
LAN	On	1000 Mbit/s	Full-duplex	143.9 K (147 345 B)	66.4 K (68 032 B)

Below the table is a 'Refresh' button.

#### State

- *Port* – port name:
  - *LAN* – local network port.
- *Connection* – port connection state:
  - *On* – network device is connected to the port (connection is active);
  - *Off* – network device is not connected to the port (connection is inactive).
- *Speed* – speed of the external network device connection to this port (10/100/1000 Mbit/s);
- *Mode* – data transmission mode:
  - *Full-duplex* – full duplex;
  - *Half-duplex* – half duplex;
- *Transmitted* – the quantity of bytes transmitted from the port;
- *Received* – the quantity of bytes received by the port.

To obtain current information on Ethernet ports states, click 'Refresh' button.

### 5.1.4 The 'DHCP' submenu

The list of network devices connected to LAN interface of the device, whose IP addresses were assigned by local DHCP server, is given in the DHCP submenu. The expire time of address lease is shown in the table as well.



The screenshot shows the DHCP submenu with a table titled 'List of DHCP Clients'. The table has four columns: MAC, Client Name, IP Address, and Lease Expires. There is one row of data and a 'Refresh' button at the bottom.

MAC	Client Name	IP Address	Lease Expires
30:65:EC:90:FB:E1	DESKTOP-PMJLVM9	192.168.1.2	11 h 55 min


#### List of DHCP Clients

- *MAC Address* – MAC address of the connected device;
- *Client Name* – network name of the connected device;
- *IP Address* – IP address assigned to client from address pool;
- *Lease Expires* – the period after which the lease of the dedicated address expires.

To obtain current information on DHCP clients, click the 'Refresh' button.

### 5.1.5 The 'ARP' submenu

You can view ARP table in the ARP submenu. ARP table contain information on IP and MAC addresses mapping.



The screenshot shows the ARP submenu with a table titled 'ARP Table'. The table has four columns: IP Address, MAC, Client Name, and Interface. There are two rows of data and a 'Refresh' button at the bottom.

IP Address	MAC	Client Name	Interface
10.24.80.29	3C:1E:04:46:97:1F		Bridge
10.24.80.1	E0:D9:E3:E8:E1:40		Bridge

#### ARP Table

- *IP address* – the device IP address;
- *MAC address* – the device MAC address;
- *Client name* – device hostname (if one is present);
- *Interface* – interface from which the device is active: WAN, LAN or Bridge.

To get current information, click the 'Refresh' button.

## 5.1.6 The 'PPPoE Relay' submenu

- ✓ The 'PPPoE Relay' submenu is only available in the 'Wi-Fi Client' device mode in the 'Bridge' operation mode.

- *Sessions Count* – the quantity of PPPoE sessions established through the device. The maximum value – 64;
- *Status* – active or inactive session;
- *Session ID* – number of session;
- *Uptime* – session uptime;
- *Client Timeout* – time since the last packet from the client is received;
- *Server Timeout* – time since the last packet from the server is received.

You can also see information about the MAC address of the client and server.

## 5.1.7 The 'PPPoE Client' submenu

- ✓ The 'PPPoE Client' submenu is available only in 'Router' mode.

On the page you can see information about the MAC address and the IP address of the client and server. The 'Status' parameter displays the session state - whether session is active or inactive.

PPPoE Client Info	
Status	ACTIVE
Client MAC	E0:D9:E3:7A:BE:40
Server MAC	5C:D9:98:F5:8C:9B
Client IP	10.10.1.10
Server IP	10.10.1.1

### 5.1.8 The 'Device info' submenu

General information on the device is given in the Device submenu.



The screenshot shows a web interface with a navigation menu at the top. The 'Monitoring' tab is selected, and the 'Device' sub-tab is active. Below the navigation, the 'Device Info' section displays a table of system parameters.

Device Info	
Product	WB-2P-LR2
Firmware Version	2.4.0.50
Factory MAC Address	E0:D9:E3:49:C1:A0
Serial Number	WP36000038
System Time	20:47:10 05.04.2020
Uptime	9 d, 04:15:22

#### Device info

- *Product* – device model name;
- *Firmware Version* – device firmware version;
- *Factory MAC Address* – device WAN interface MAC address, setted by manufacturer;
- *Serial Number* – device serial number, setted by manufacturer;
- *System Time* – current time and date, setted in system;
- *Uptime* – the time since the last turn on or restart of the device.

## 5.1.9 The 'Contrack' submenu

In the 'Contrack' submenu you can find the current active network connections of the device.

The screenshot displays the 'Contrack' submenu with the following sections:

**Active NAT Session**

Active Connections	19
Shown Connections	19

**Connections List**

Protocol	Source Address	Destination	Timeout
UNKNOWN	192.168.1.1	224.0.0.1	9 min 56 s
UDP	127.0.0.1:58279	127.0.0.1:63	14 s
UDP	0.0.0.0:88	255.255.255.255:67	22 s
TCP	100.110.0.13:56823	100.110.0.243:80	4 min 32 s
UDP	100.110.0.243:38840	172.16.0.100:53	3 s
TCP	100.110.0.13:56834	100.110.0.243:80	1 min 56 s
UDP	100.110.0.243:38840	100.110.1.253:53	3 s
TCP	100.110.0.13:56836	100.110.0.243:80	4 d 23 h 59 min 58 s
TCP	100.110.0.13:56835	100.110.0.243:80	4 d 23 h 59 min 57 s
TCP	100.110.0.13:56837	100.110.0.243:80	4 d 23 h 59 min 59 s
UDP	127.0.0.1:35513	127.0.0.1:63	3 s
TCP	100.110.0.13:56824	100.110.0.243:80	1 min 31 s
UNKNOWN	100.110.0.238	239.255.255.250	9 min 38 s
UNKNOWN	100.110.0.238	224.0.0.251	9 min 38 s
TCP	100.110.0.13:56838	100.110.0.243:80	4 d 23 h 59 min 58 s
TCP	100.110.0.13:56839	100.110.0.243:80	4 d 23 h 59 min 57 s
UDP	100.110.0.243:38840	172.16.0.250:53	3 s
UNKNOWN	100.110.0.238	224.0.0.252	9 min 38 s
TCP	100.110.0.13:56833	100.110.0.243:80	4 d 23 h 59 min 56 s

At the bottom of the interface is a 'Refresh' button.

### Active NAT Session

- *Active Connections Count* – total number of active network connections;
- *Shown Connections* – number of connections shown in the web interface. In order to maintain high performance of the web interface, the maximum number of connections shown is limited to 1024. You can view other connections through the device console

### Connections List

- *Protocol* – protocol by which the connection has been established;
- *Source Address* – connection initiator IP address and port number;
- *Destination IP* – connection destination IP address and port number;
- *Timeout* – time period before the disconnection.

To get current information, click the 'Refresh' button.

### 5.1.10 The 'Routes' submenu

In the Routes submenu you can view the device route table.

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
0.0.0.0	100.110.0.1	0.0.0.0	UG	0	0	0	wlan0
100.110.0.0	0.0.0.0	255.255.254.0	U	0	0	0	wlan0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	br0

- *Destination* – IP address of destination host or subnet that the route should be established to;
- *Gateway* – gateway IP address that allows for the access to the Destination.
- *Netmask* – subnet mask;
- *Flags* – certain route characteristics. The following *flag* values exist:
  - **U** – means that the route is created and passable.
  - **H** – identifies the route to the specific host;
  - **G** – means that the route lies through the external gateway. System network interface provides routes in the network with direct connection. All other routes lie through the external gateways. G flag is used for all routes except for the routes in the direct connection networks.
  - **R** – indicates that the route was most likely created by a dynamic routing protocol running on the local system using the *reinstat* parameter;
  - **D** – indicates that the route was added as a result of receiving an ICMP Redirect Message. When the system learns the route from the ICMP Redirect message, the route will be added into the routing table in order to exclude redirection of the following packets intended for the same destination.
  - **M** – means that the route was modified – likely by a dynamic routing protocol running on a local system with the *'mod'* parameter applied;
  - **A** – points to a buffered route to which an entry in the ARP table corresponds.
  - **C** – means that the route source is the core routing buffer.
  - **L** – indicates that the destination of the route is one of the addresses of this computer. Such *'local routes'* exist in the routing buffer only.
  - **B** – means that the route destination is a broadcasting address. Such *'broadcast routes'* exist in the routing buffer only.
  - **I** – indicates that the route is connected to a ring (loopback) interface for a purpose other than to access the ring network. Such *'internal routes'* exist in the routing buffer only.
  - **!** – means that datagrams sent to this address will be rejected by the system.
- *Metric* – determines route *'price'*. Metrics allows you to sort the duplicate routes, if they are exist in the table.
- *Ref* – fixed number of calls to the route to create a connection (not used in the system);
- *Use* – number of route detections performed by IP protocol.
- *Interface* – the name of the network interface through which this route runs.

To get current information, click the *'Refresh'* button.

## 5.2 The 'Network' menu

You can implement main network settings in the 'Network' menu.

### 5.2.1 The 'Internet' submenu

In 'Internet' submenu, you can configure parameters to connect to a base station via Wi-Fi and select connection mode.

#### Wi-Fi Client mode

The screenshot displays the 'Network' configuration page with the 'Internet' submenu selected. The 'Common Settings' section includes a 'Hostname' input field. The 'WAN' section shows 'Device Mode' set to 'Wireless Station'. The 'Connection Settings' section is expanded, showing various parameters: SSID (WOP-2ac-LR2), 802.11 Mode (802.11bgn), Channel Bandwidth (40 MHz), Security Mode (WPA2), WPA Key (masked), Tx Power (26 dBm), Short Guard Interval (checked), Fixed Center Frequency (unchecked), Limit Channels (unchecked), Fixed Transmit Rate (Auto), Maximal Transmit Rate (Auto), ACK Timeout (64 µs), Network Mode (Bridge), Priority (DSCP), Protocol (DHCP), VLAN Trunk Mode (unchecked), Alternative Vendor ID (checked), Vendor ID (empty), Primary DNS Server (empty), Secondary DNS Server (empty), Tx Broadcast Rate Limit (0 packets/sec), and Traffic Shaper (unchecked). At the bottom, there are 'Apply' and 'Cancel' buttons.

- *Hostname* – a name of the network device;
- *Device mode* – a mode of device connection;

WAN

Device Mode

Connection Settings

SSID

802.11 Mode

Channel Bandwidth

Security Mode

WPA Key

Tx Power (dBm)

Short Guard Interval

Fixed Center Frequency

Limit Channels

Fixed Transmit Rate

Maximal Transmit Rate

ACK Timeout,  $\mu$ s

Network Mode

SSID	Security	MAC	Channel	Bandwidth, MHz	Frequency, MHz	RSSI, dBm
WOP-2ac-LR2	WPA/WPA2	E0:D9:E3:91:23:11	4	40L	2437	-58
i-OTT-ent-05	WPA_1X/WPA2_1X	E0:D9:E3:70:59:20	6	20	2437	-84
i-OTT-05-portal	Open	E0:D9:E3:70:59:21	6	20	2437	-86
Hotspot-GRE-Test	Open	E8:28:C1:01:27:70	6	40L	2447	-86
proverkav	Open	E8:28:C1:01:27:71	6	40L	2447	-90

- **SSID** – wireless network ID, which is used for base station connection. The maximum name length – 32 symbols, the keyboard register is important. The name may consist of digits, latin letters and symbols '-', '\_', '.', '!', ',', ';', '#', and space, although it is forbidden to start with the symbols '!', ',', '#', and space;
- **Scan Environment** – click the button to start scanning at the defined range. The list of found access points will be displayed. The list of access points consists of seven columns: access point SSID, security mode, MAC address, channel, channel bandwidth, frequency, signal level. If you select any access point from the list, SSID field will be filled automatically, and the corresponding mode will be selected;
- **802.11 Mode** – operation mode according to the standard:
  - *802.11bg* – maximum rate is up to 54 Mbps;
  - *802.11bgn* – maximum rate is up to 300 Mbps;
  - *802.11n* – maximum rate is up to 300 Mbps.
- **Channel Bandwidth** – channel bandwidth, on which a Wi-Fi client operates. The parameter may take values from 5, 10, 20 and 40 MHz. If the base station has 5 or 10 MHz bandwidth, you should select the same bandwidth on the user station.
- **Security mode** – select security mode for wireless network:
  - *Off* – encryption of the wireless network is off, low security;
  - *WEP* – WEP encryption. WEP-key should consist of hexadecimal digits and be of 10 or 26 symbols length or it might be a string (a-z, A-Z, 0-9, ~!@#%&\*()\_+= symbols) with length of 5 or 13 symbols. The mode is hidden in the web interface;
  - *WPA, WPA2* – WPA and WPA2 authentication. The key length is from 8 to 63 symbols. Only the following characters can be used: a-z, A-Z, 0-9, ~!@#%&\*()\_+=;|/?.,<>"' or space. It is recommended to use WPA and WPA2 encryption modes as the safest;
  - *WPA-Enterprise, WPA2-Enterprise* – WPA and WPA2 encryption with client authentication via 802.1x. Enter username and password as authentication data.
- **Tx Power (dBm)** – transmitting Wi-Fi signal power adjustment, dBm.
- **Short Guard Interval** – support for shortened guard interval. 400 ns interval is used (instead of 800 ns).
- **Fixed center frequency** – when the flag is checked, all traffic (data and management packets) will be transmitted on the specified center channel frequency with a given bandwidth (40 MHz). The function is proprietary, the transmission is not carried out according to IEEE 802.11 standards, where it is supposed to use different center frequencies for data and management traffic with 40 MHz bandwidth. When using the WB-2P-LR2 with WOP-2ac-LR2 devices with enabled fixed center frequency, activation at the subscriber station is not required, because happens automatically at the moment of connection to the base station.

- *Limit Channels* – the list of frequencies on which the air is scanned to connect to the base station.

For example, if a channel 1L (2402-2442) with a 40 MHz band is set on the BS, then in the list of allowed channels should be selected *all the channels in this frequency range* : 1 - 7 channel inclusive. With this setting, the WB-2P-LR2 will only scan the frequency range of 2402 - 2442 MHz and successfully connect to the BS on the 1L/40 channel;

WAN

Device Mode Wireless Station

Connection Settings

SSID WOP-2ac-LR2

802.11 Mode 802.11bgn

Channel Bandwidth 20 MHz

Security Mode WPA2

WPA Key ••••••••

Tx Power (dBm) 26

Short Guard Interval

Limit Channels

1 (2412 MHz) ✕ 2 (2417 MHz) ✕ 3 (2422 MHz) ✕ 4 (2427 MHz) ✕ 5 (2432 MHz) ✕ 6 (2437 MHz) ✕ 7 (2442 MHz) ✕

- *Fixed Transmit Rate* – fixed wireless data transmission rate which is defined by IEEE 802.11b/g/n standards;
- *Maximum Transmit Rate* – maximum allowed wireless data transmission rate which is defined by IEEE 802.11b/g/n standards;
- *ACK Timeout* – packet confirmation waiting timeout. When the distance is long (more than 2.5 km), the parameter is recommended to be increased choosing the optimal value;
- *Network Mode* – device operation mode:
  - *Router* – router mode between LAN and WAN interfaces (WAN interface is the wireless Wi-Fi interface, LAN is isolated from WAN);
  - *Bridge* – bridge mode between wired and wireless interfaces of the device.
- *Priority* – select prioritization means. Defines a field based on which traffic transmitted to the radio interface will be distributed among WMM queues:
  - *DSCP* – enables analization of priority from the DSCP field of IP packet header;
  - *802.1p* – enables analization of priority from the CoS (Class of Service) field of tagged packets.
- *Protocol* – select protocol for connection of the device via Wi-Fi interface to service provider network:
  - *Static* – operation mode where IP address and all the necessary parameters for WAN interface are assigned statically. If 'Static' is selected, the following parameters will be available to set:
    - *WAN IP* – set IP address of WAN interface of the device in service provider network;
    - *Netmask* – set subnet mask of device's WAN interface in service provider network;
    - *Default gateway* – address where the packet will be sent to, when route for it is not found in the routing table;
  - *DHCP* – operation mode where IP address, subnet mask, DNS address, default gateway and other necessary settings for network operation are automatically obtained from DHCP server. Before obtaining the parameters via DHCP, the access to the device is implemented via address set in IP address field.
    - *Alternative Vendor ID (Option 60)* – when selected, the device transmits *Vendor ID (Option 60) in Option 60 DHCP messages (Vendor class ID)*. If the field is empty, Option 60 will not be transmitted in DHCP messages.  
If the parameter Alternative Vendor ID (Option 60) is not checked, the default value will be transmitted in option 60. The default value has the following format:  
[VENDOR:device vendor][DEVICE:device type][HW:hardware version] [SN:serial number]  
[WAN:WAN interface MAC address][LAN:LAN interface MAC address][VERSION:firmware

version]

Example:

```
[VENDOR:Eltex][DEVICE:WB-2P-LR2][HW:1.2][SN:WP29000038] [WAN:E0:D9:E3:75:55:60]
[LAN:E0:D9:E3:75:55:60][VERSION:2.0.0.161]
```

- *PPPoE (available in the router mode)* – operation mode when PPP session is established on WAN interface; When PPPoE is selected, the following parameters will be available for editing:
  - *Username* – user name for authorization on PPP server;
  - *Password* – password for authorization on PPP server;
  - *MTU* – the maximum packet size that can be transmitted through a PPP session without fragmentation;
  - *Service-Name* – service provider name. Service-Name tag value in PADI message for PPPoE connection (this parameter is optional, and configured only on the provider's request);
  - *Secondary access* – type of access to local network resources.
    - *DHCP* – operation mode where IP address, subnet mask, DNS address, default gateway and other necessary settings for network operation are automatically obtained from DHCP server;
    - *Static* – operation mode, when IP address and other necessary parameters of WAN interface are set statically. If 'Static' is selected, the following parameters will be available to set:
      - *External IP address* – specify device WAN interface IP address in the provider network;
      - *Netmask* – set subnet mask of device's WAN interface in service provider network;
      - *Default gateway* – address where the packet will be sent to, when route for it is not found in the routing table;
      - *Primary DNS, Secondary DNS* – DNS IP address – if DNS addresses are not automatically assigned via DHCP, you should defined them manually.
- *Disable sender address translation (available in router mode)* – the option allows you to disable sender address broadcasting (masquerade);
- *Tx Broadcast Rate Limit (packets/sec)* – limits transmission to external Wi-Fi network;
- *Traffic Shaper* – rate limit of both Downlink and Uplink directions. The maximum limit is 200 Mbps.

## VLAN trunk in bridge mode

VLAN Trunk Mode	<input checked="" type="checkbox"/>
Use Management VLAN	<input checked="" type="checkbox"/>
Management VLAN ID	<input type="text" value=""/>
Management 802.1P	<input type="text" value="0"/>
Management VLAN Access	<input type="text" value="Ethernet and wireless"/>

- *VLAN Trunk* – if checked, the trunk port is activated for connected devices. The device will transparently transmit all VLANs (including 'Restrict VLAN list' option) received from the base station to wired clients and vice versa. At the same time, the passage of untagged traffic depends on the "Transparent mode" option;
  - *Use Management VLAN* – when checked, management VLAN used for access to the device is enabled:
    - *Management VLAN ID* – VLAN identifier, which is used to access the device;
    - *Management 802.1P* – 802.1P attribute (also called CoS – Class of Service), which is attached to egress packets transmitted from this interface. The value is from 0 (the least priority) to 7 (the highest priority);

- *Management VLAN Access* – restrict access to the management network. Possible values:
  - *Ethernet and wireless* – access to the management network is possible from the wireless and Ethernet interfaces;
  - *Wireless* – access to the management network is only possible from the wireless interface side.

✓ If the “Use Management VLAN” flag is checked and the Management VLAN is configured incorrectly, access to the device can be lost. When connected via Ethernet, the device will be available at 192.0.3.1.

- *Limit VLAN-list* – when checked, the device in VLAN trunk mode will pass only a limited number of VLANs, which are specified in the "VLAN list" field.
  - *VLAN list* – contains VLAN identifiers that are allowed for transmission. Accepts values from 1 to 4094, it is possible to specify a range, for example "2000-2010".

- *Use General VLAN* – when checked, one VLAN specified in the General VLAN ID field will be removed and the traffic of this VLAN will go to the client without a tag. When traffic flows in the opposite direction, untagged traffic will be tagged with General VLAN ID:
  - *General VLAN ID* – VLAN identifier;
  - *General 802.1P* – 802.1P attribute (also called CoS – Class of Service), which is attached to egress packets transmitted from this interface. The value is from 0 (the least priority) to 7 (the highest priority).
- *Transparent mode* – when checked, the device will pass untagged traffic in the VLAN trunk mode.

- *Enable MVR* – when checked, Multicast VLAN Registration is enabled. The function allows you to use a separate VLAN for multicast traffic. In this case the traffic to the subscriber is transmitted without a tag. The parameter is available for configuration if "Use General VLAN" or "Transparent mode" is enabled:
  - *MVR VLAN ID* – ID of the VLAN in which the multicast traffic is transmitted;
  - *MVR 802.1P* – 802.1P attribute (also called CoS – Class of Service), that is set on packets originating on this interface. May take values from 0 (lowest priority) to 7 (highest priority). Default – 7.

## VLAN Trunk in router mode

- *VLAN Trunk* – if checked, the trunk port is activated for connected devices. There is an opportunity to use Management VLAN and Internet VLAN:

VLAN Trunk Mode	<input checked="" type="checkbox"/>
Use Management VLAN	<input checked="" type="checkbox"/>
Management VLAN ID	<input type="text"/>
Management 802.1P	<input type="text" value="0"/>
Management Protocol	<input type="text" value="Static"/>
Management IP Address	<input type="text" value="192.168.15.200"/>
Management Netmask	<input type="text" value="255.255.255.0"/>
Management Default Gateway	<input type="text" value="192.168.15.1"/>

- *Use Management VLAN* – when checked, management VLAN used for access to the device is enabled:
  - *Management VLAN ID* – VLAN identifier, which is used to access the device;
  - *Management 802.1P* – 802.1P attribute (also called CoS – Class of Service), which is attached to egress packets transmitted from this interface. The value is from 0 (the least priority) to 7 (the highest priority).
  - *Management Protocol* – defines management interface operation mode:
    - *DHCP* – operation mode where IP address, subnet mask, DNS address, default gateway and other necessary settings for network operation are automatically obtained from DHCP server.
    - *Static* – operation mode where IP address and all the necessary parameters for interface are assigned statically. If 'Static' is selected, the following parameters will be available to set:
      - *Management IP* – set IP address of interface of the device in service provider network;
      - *Management netmask* – set subnet mask of device's interface in service provider network;
      - *Management Default Gateway* – address, to which a packet will be transmitted in case the route has not been found in the route table;

VLAN Trunk Mode	<input checked="" type="checkbox"/>
Use Management VLAN	<input type="checkbox"/>
Use Internet VLAN	<input checked="" type="checkbox"/>
Internet VLAN ID	<input type="text"/>
Internet 802.1P	<input type="text" value="0"/>
Internet Protocol	<input type="text" value="Static"/>
Internet IP Address	<input type="text" value="192.168.12.200"/>
Internet Netmask	<input type="text" value="255.255.255.0"/>
Internet Default Gateway	<input type="text" value="192.168.12.1"/>

- *Use Internet VLAN* – when checked, the VLAN is enabled to transmit user traffic.
  - *Internet VLAN ID* – VLAN identifier;

- *Internet 802.1P* – 802.1P attribute (also called CoS – Class of Service), which is attached to egress packets transmitted from this interface. The value is from 0 (the least priority) to 7 (the highest priority);
- *Internet Protocol* – select operation mode of the device interface, used to to transmit user traffic in a separate VLAN:
  - *DHCP* – operation mode where IP address, subnet mask, DNS address, default gateway and other necessary settings for network operation are automatically obtained from DHCP server;
  - *Static* – operation mode where IP address and all the necessary parameters for WAN interface are assigned statically. If 'Static' is selected, the following parameters will be available to set:
    - *Internet IP* – set IP address of WAN interface of the device in service provider network;
    - *Internet Netmask* – set subnet mask of device's WAN interface in service provider network;
    - *Internet Default Gateway* – address, to which a packet will be transmitted in case the route has not been found in the route table.

If *PPPoE* is selected as the Internet protocol, then you can specify the secondary access settings:

VLAN Trunk Mode	<input checked="" type="checkbox"/>
Use Management VLAN	<input type="checkbox"/>
Use Internet VLAN	<input checked="" type="checkbox"/>
Internet VLAN ID	<input type="text"/>
Internet 802.1P	0 ▼
Internet Protocol	PPPOE ▼
User Name	admin
Password	*****
MTU	1492
Service-Name	<input type="text"/>
Secondary Access	Static ▼
WAN IP Address	192.168.12.200
Netmask	255.255.255.0
Default Gateway	192.168.12.1
DNS Server	<input type="text"/>

- *Secondary access* – defines the method of setting the IP address on the interface for accessing the device if the management VLAN is not used:
  - *DHCP* – operation mode, when IP address, subnet mask, DNS server address, default gateway and other parameters required for operation are obtained from DHCP server automatically;
  - *Static* – operation mode, when IP address and other necessary parameters of WAN interface are set statically (manually). If 'Static' is selected, the following parameters will be available to set:
    - *External IP address* – specify device WAN interface IP address in the provider network;
    - *Netmask* – set subnet mask of device's WAN interface in service provider network;
    - *Default Gateway* – address, to which a packet will be transmitted in case the route has not been found in the route table;
    - *DNS server* – domain name server address (allows identifying the IP address of the device by its domain name).

**VLAN** is a virtual local area network. VLAN consists of a group of hosts combined into a single network regardless of their location. The devices grouped to a VLAN have the same identifier VLAN-ID.

## Wireless bridge mode

Common Settings

Hostname

WAN

Device Mode ▼ Wireless Bridge

Connection Settings

Priority ▼ DSCP

Protocol ▼ DHCP

VLAN Trunk Mode

Alternative Vendor ID (option 60)

Vendor ID (option 60)

Primary DNS Server

Secondary DNS Server

WDS Settings

Security Mode ▼ Off

MAC Setting

Link 0

Link 1

Link 2

Link 3

Link 4

Link 5

Link 6

Link 7

## WAN

- *Hostname* – a name of the network device;
- *Device mode* – a mode of device connection;
- *Priority* – select prioritization means. Defines a field based on which traffic transmitted to the radio interface will be distributed among WMM queues:
  - *DSCP* – enables analysis of priority from the DSCP field of IP packet header;
  - *802.1p* – enables analysis of priority from the CoS (Class of Service) field of tagged packets.
- *Protocol* – defines operation mode of the interface through which the connection of the device to service provider network will be performed:
  - *Static* – operation mode where IP address and all the necessary parameters for WAN interface are assigned statically. If 'Static' is selected, the following parameters will be available to set:
    - *WAN IP* – set IP address of WAN interface of the device in service provider network;
    - *Netmask* – set subnet mask of device's WAN interface in service provider network;
    - *Default gateway* – address where the packet will be sent to, when route for it is not found in the routing table.
  - *DHCP* – operation mode where IP address, subnet mask, DNS address, default gateway and other necessary settings for network operation are automatically obtained from DHCP server. Before obtaining the parameters via DHCP, the access to the device is implemented via address set in IP address field:

- *Alternative Vendor ID (Option 60)* – when selected, the device transmits *Vendor ID (Option 60)* in *Option 60 DHCP messages (Vendor class ID)*. If the field is empty, Option 60 will not be transmitted in DHCP messages.

If the parameter *Alternative Vendor ID (Option 60)* is not checked, the default value will be transmitted in option 60. The default value has the following format:

[VENDOR:device vendor][DEVICE:device type][HW:hardware version] [SN:serial number][WAN:WAN interface MAC address][LAN:LAN interface MAC address][VERSION:firmware version]

Example:

[VENDOR:Eltex][DEVICE:WB-2P-LR2][HW:1.2][SN:WP29000038] [WAN:E0:D9:E3:75:55:60]  
[LAN:E0:D9:E3:75:55:60][VERSION:2.0.0.161]

- *Primary DNS, Secondary DNS* – DNS Ip address – if DNS addresses are not automatically assigned via DHCP, you should defined them manually.
- *VLAN Trunk* – if checked, the trunk port is activated for connected devices. There is an opportunity to use Management VLAN:
  - *Use Management VLAN* – when checked, management VLAN used for access to the device is enabled:
    - *Management VLAN ID* – VLAN identifier, which is used to access the device;
    - *Management 802.1P* – 802.1P attribute (also called CoS – Class of Service), which is attached to egress packets transmitted from this interface. The value is from 0 (the least priority) to 7 (the highest priority).
    - *Management VLAN Access* – restrict access to the management network. Possible values:
      - *Ethernet and wireless* – access to the management network is possible from the wireless and Ethernet interfaces;
      - *Wireless* – access to the management network is only possible from the wireless interface side.
  - *Limit VLAN-list* – when checked, the device in VLAN trunk mode will pass only a limited number of VLANs, which are specified in the "VLAN list" field.
    - *VLAN list* – contains VLAN identifiers that are allowed for transmission. Accepts values from 1 to 4094, it is possible to specify a range, for example "2000-2010".

## WDS Settings

- *Security mode* – select security mode for wireless bridge:
  - *Off* – wireless network encryption is off, low security;
  - *WPA2* – WPA2 authentication. The length of the key makes from 8 to 11 characters. Only the following characters can be used: a-z, A-Z, 0-9, ~!@#\$%^&\*()\_+ = ; | / ? . , < > " ' ` or space.
- *Link X (where X=0..7)* – enable wireless bridge link. Enter MAC address of the device, to which you want to configure the wireless bridge, to a corresponding field next to Link checkbox.

## 5.2.2 The 'Radio' submenu

✔ The 'Radio' submenu is available only in the 'Wireless bridge' mode.

In the 'Radio' submenu, you can configure the radiointerface to organize wireless bridge.

*Basic settings:*

The screenshot displays the 'Radio' configuration interface for a Wi-Fi 2.4 GHz network. The interface is organized into tabs: 'Monitoring', 'Network' (selected), and 'System'. Under 'Network', there are sub-tabs for 'Internet', 'Radio' (selected), 'MAC Management', 'Firewall', 'Routes', and 'SNMP'. The main heading is 'Wi-Fi 2.4 GHz', with sub-tabs for 'Basic Settings' and 'Advanced Settings'. The configuration fields are as follows:

- 802.11 Mode:** 802.11bgn (dropdown menu)
- Channel:** 1 (2412 MHz) (dropdown menu)
- Channel Bandwidth:** 20 MHz (dropdown menu)
- Tx Power (dBm):** 26 (text input)
- Fixed Transmit Rate:** Auto (dropdown menu)
- Maximal Transmit Rate:** Auto (dropdown menu)
- ACK Timeout, µs:** 64 (text input)

At the bottom right, there is a blue 'Scan Environment' button with a magnifying glass icon. At the bottom left, there are 'Apply' and 'Cancel' buttons.

- *Scan Environment* – click the button to start scanning at the defined range. The list of found access points will be displayed. The list of access points consists of seven columns: access point SSID, security mode, MAC address, channel, channel bandwidth, frequency, signal level.
- *802.11 Mode* – operation mode according to the standard:
  - *802.11bg* – maximum rate is up to 54 Mbps;
  - *802.11bgn* – maximum rate is up to 300 Mbps;
  - *802.11n* – maximum rate is up to 300 Mbps.
- *Channel* – select channel for data transmission.
- *Channel Bandwidth* – channel bandwidth, on which the radiointerface operates. The parameter may take values from 5, 10, 20 and 40 MHz according to selected mode.
- *Fixed center frequency* – when the flag is checked, all traffic (data and management packets) will be transmitted on the specified center channel frequency with a given bandwidth (40 MHz). The function is proprietary, the transmission is not carried out according to IEEE 802.11 standards, where it is supposed to use different center frequencies for data and management traffic with 40 MHz bandwidth;
- *Tx Power (dBm)* – transmitting Wi-Fi signal power adjustment, dBm.
- *Fixed Transmit Rate* – fixed wireless data transmission rate which is defined by IEEE 802.11 g/n standards;
- *Maximum Transmit Rate* – maximum allowed wireless data transmission rate which is defined by IEEE 802.11 g/n standards.

Advanced settings:

Monitoring **Network** System

Internet **Radio** MAC Management Firewall Routes SNMP

Wi-Fi 2.4 GHz

Basic Settings **Advanced Settings**

Fragmentation Threshold  (256-2346)

RTS Threshold  (0-2347)

Beacon Interval, ms  (20-1024)

Aggregation

Short Guard Interval

STBC

Coexistence 20/40 MHz

- *Fragmentation Threshold* – frame fragmentation threshold, bytes. The parameter takes values 256-2346, by default – 2346;
- *RTS Threshold* – after what quantity of bytes the Request to Send will be sent. Decreasing of the parameter's value might improve access point operation when there are a lot of clients connected. However, decreasing of the parameter's value will reduce general bandwidth of wireless network. The parameter takes values from 0 to 2347, by default – 2347;
- *Beacon Interval, ms* – beacon frames transmission period. The frames are sent to detect access points. The parameter takes values from 20 to 2000 ms, by default – 100 ms;
- *Aggregation* – enable support for AMPDU/AMSDU;
- *Short Guard interval* – support for shortened guard interval. 400 ns interval is used (instead of 800 ns).
- *STBC* – Space-Time Block Coding method dedicated to improve data transmission reliability. When checked, the device transmits one data flow through several antennas. When unchecked, the device does not transmit one data flow through several antennas;
- *Coexistence 20/40 MHz* – automatic bandwidth changing when environment is loaded.

 **For wireless bridge operation, radiointerface parameters should be configured identically on all the devices.**

### 5.2.3 The 'LAN' submenu

✓ **The 'LAN' submenu is available only in the 'Router' mode.**

In DHCP server settings section you can configure local network, DHCP server, set static addresses bindings.

The device is capable to assign IP addresses and other parameters required to the Internet access to computers connected to LAN interface through DHCP (Dynamic Host Configuration Protocol). The use of DHCP allows to avoid manual configuration of TCP/IP.

The screenshot displays the LAN configuration interface. At the top, there are navigation tabs: Monitoring, Network (selected), IPTV, and System. Under the Network tab, there are sub-tabs: Internet, LAN (selected), MAC Management, Local DNS, NAT and Port Forwarding, Firewall, Routes, Dynamic DNS, and SNMP. The main content area is titled 'LAN' and contains the following settings:

- IP Address:** 192.168.1.1
- Netmask:** 255.255.255.0
- DHCP Server Settings:**
  - Enable:**
  - Start IP Address:** 192.168.1.2
  - Pool Size:** 250
  - Lease Time (min):** 720
- Buttons:** 'Apply' (checked) and 'Cancel'.
- Static Leases:** A table with columns 'Name', 'MAC', and 'IP Address'. Below the table are '+ Add' and 'Remove' buttons.

#### LAN:

- *IP address* – IP address of the device in a local network;
- *Netmask* – subnetmask in local network.

#### DHCP server settings:

- *Enable* – when checked, a local DHCP server is enabled, otherwise the server is disabled;
- *Start IP address* – the initiate address of the IP addresses pool;
- *Pool size* – number of addresses in the pool;
- *Lease time (min)* – set the maximum time range for using an IP address assigned by DHCP server, lease time is set in minutes.

To apply a new configuration and store settings into the non-volatile memory, click the 'Apply' button. To discard changes click the 'Cancel' button.

✓ **When you try to change the starting address of the DHCP pool to an address from a different subnet with respect to the subnet of the LAN interface, the pool is automatically set in accordance with the specified local subnet.**

### Static leases

To set new static lease, click the 'Add' button and fill the following fields:

- *Name* – lease name
- *MAC address* – specify a static MAC address. It is assigned in XX:XX:XX:XX:XX:XX format;
- *IP address* – define a static IP address for the specific MAC address.

Configuring of static leases is helpful when you need that the certain computer always obtains certain IP address.

Click 'Apply' to add IP address to the list of static IP addresses for DHCP server. To discard changes click the 'Cancel' button.

To delete an address from the list, select the corresponding checkbox and click 'Remove'.

### 5.2.4 The 'MAC Management' submenu

In the MAC address Management submenu, you can set MAC address of the device's WAN interface.

### Wireless transparent bridge

✔ **'Wireless transparent bridge' settings are available for Bridge mode of Wi-Fi station only.**

When you enable Wireless transparent bridge, WB-2P-LR2 will not substitute client MAC addresses from LAN with own MAC address. The limit is 15 MAC addresses without substitution. When the value is exceeded client's MAC address will be substituted. The section of connected clients on a base station will include MAC addresses of client devices from LAN.

### Set MAC address for WAN

- *Redefine MAC* – when checked, the MAC address from the field MAC is used.


To apply a new configuration and save setting to non-volatile memory, click 'Apply'. Click 'Cancel' to discard the changes.

## 5.2.5 The 'Local DNS' submenu

✓ **The local DNS submenu is available only in router mode.**

You can configure Local DNS server of the device by adding IP address and domain name in the 'Local DNS' submenu.


Local DNS allows to obtain an IP address of the device using its domain name (host) in case of lack of DNS server in a network segment. To implement this, you should know concordances between nodes names (hosts) and their IP addresses.



The screenshot shows the 'Local DNS' configuration page. At the top, there are tabs for 'Monitoring', 'Network' (selected), 'IPTV', and 'System'. Under 'Network', there are sub-tabs: 'Internet', 'LAN', 'MAC Management', 'Local DNS' (selected), 'NAT and Port Forwarding', 'Firewall', 'Routes', 'Dynamic DNS', and 'SNMP'. The main content area is titled 'List of Domain Names' and contains a table with two columns: 'Domain Name' and 'IP Address'. Below the table, there are two buttons: '+ Add' and 'Remove'.

### Configuring nodes

To add the address into the list, click the 'Add' button in the 'New domain name' window and fill in the following fields:



The screenshot shows the 'New Domain Name' configuration window. At the top, there are tabs for 'Monitoring', 'Network' (selected), 'IPTV', and 'System'. Under 'Network', there are sub-tabs: 'Internet', 'LAN', 'MAC Management', 'Local DNS' (selected), 'NAT and Port Forwarding', 'Firewall', 'Routes', 'Dynamic DNS', and 'SNMP'. The main content area is titled 'New Domain Name' and contains two input fields: 'Domain Name' and 'IP Address'. Below the fields, there are two buttons: 'Apply' and 'Cancel'.

- *Domain name* – host name;
- *IP Address* – IP address of the host.

Click 'Apply' to create concordance IP address – domain name. To discard changes click the 'Cancel' button. To delete an entry from the list, select corresponding checkbox and click 'Remove'.

## 5.2.6 The 'NAT and Port Forwarding' submenu

✔ **The NAT and Port Forwarding submenu is available only for router mode.**

You can configure Port Forwarding from WAN interface to LAN interface in the NAT and Port Forwarding submenu.

NAT (Network Address Translation) mode allows to modify IP addresses and network ports of IP packets. Port forwarding is necessary when TCP/UDP connection with local PC (connected to LAN interface) is established via external network. The settings menu allows to set rules which permit packets transmission from external network to specified address in a local network, i.e. to establish connection. Port forwarding is also necessary when using torrent and p2p services. To implement the configuration, find TCP/UDP ports used by torrent or p2p clients in settings and set them for corresponding port forwarding rules to a PC IP address.

Monitoring **Network** IPTV System

Internet LAN MAC Management Local DNS **NAT and Port Forwarding** Firewall Routes Dynamic DNS SNMP

### NAT Settings

Enable NAT

### NAT Rules

	Name	LAN IP	LAN Ports	Protocol	WAN IP	WAN Ports
<input type="checkbox"/>	Rule-1	192.168.1.3	50002	TCP	76.44.23.56	50000
<input type="checkbox"/>	Rule-2	192.168.1.3	50005	UDP	213.45.66.89	50005

### NAT rules

To add a new NAT rule, click the 'Add' button and fill in the following fields in the Add a new rule window:

### Add a New Rule

Name

LAN IP Address

Destination Ports of LAN

Protocol

WAN IP Address

Destination Ports of WAN

- *Name* – name of the rule (this field is mandatory);
- *LAN IP Address* – IP address of host in local network. Packets translated to this host will follow the rule;

- *Destination ports of LAN* – receiver TCP/UDP ports, via which packets are translated to local network (you can assign either single port or range of ports using dash);
- *Protocol* – selection of the packet protocol falling under this rule: TCP, UDP, TCP/UDP;
- *WAN IP address* – source IP address in external network which will be under the rule;
- *Destination Ports of WAN* – destination TCP/UDP ports in external network, packets from which will follow the rule (you can assign either single port or range of ports using dash).


Port forwarding rule will work as follows: a packet received via '*Protocol*' on a port defined in '*Destination Ports of WAN*' field and having source address defined in '*WAN IP address*' field (if the field is empty, source IP does not consider) undergoes address and Destination port substitute with the parameters defined in '*LAN IP Address*' and '*Destination Ports of LAN*' fields respectively.

Click '*Apply*' to create concordance IP address – domain name. To discard changes, click '*Cancel*'.

To delete an entry from the list, select corresponding checkbox and click '*Remove*'.

### 5.2.7 The 'Firewall' submenu

The rules for incoming, outgoing and transit traffic transmission are set in the *Firewall* submenu. There is an opportunity to limit transmission of different types of traffic (incoming, outgoing, transit) depending on protocol type, source and destination IP, TCP/UDP source and destination ports, type of ICMP message.



#### Configuring firewall rules

To add a new NAT rule, click the '*Add*' button and fill in the following fields in the '*Add a new rule*' window:

The 'Add a New Rule' dialog box contains the following fields:

- Name:
- Traffic Type:
- Protocol:
- Source IP Address:
- Source Ports:
- Destination Ports:
- Action:

At the bottom, there are two buttons: 'Apply' and 'Cancel'.

- *Name* – rule name;
- *Traffic type* – select the traffic type that will fall under this rule:
  - *Incoming* – incoming device traffic (recipient is one of the device network interfaces). If the parameter is selected, the following field will be displayed:
    - *Source address* – define starting source IP address. You can set subnet mask after '/' character. The subnet mask should be set in the following formats: xxx.xxx.xxx.xxx or xx, e.g. 192.168.16.0/24 or 192.168.16.0/255.255.255.0 to set addresses range (the subnet mask entry /24 coincides with /255.255.255.0 entry);
  - *Outgoing* – outgoing device traffic (traffic generated locally by the device from one of the network interfaces). If the parameter is selected, the following field will be displayed:
    - *Destination IP address* – set destination IP address. You can set subnet mask after '/' character. The subnet mask should be set in the following formats: xxx.xxx.xxx.xxx or xx, e.g. 192.168.16.0/24 or 192.168.16.0/255.255.255.0 to set addresses range (the subnet mask entry /24 coincides with /255.255.255.0 entry);
  - *Protocol* – packet protocol that will fall under this rule: TCP, UDP, TCP/UDP, ICMP, any.
  - *Action* – action to be performed on packets (reject/skip).

When TCP, UDP, TCP/UDP protocols are selected, the following settings will be available to configure:

- *Source ports* – the list of source ports, packets from which will follow the rule (it is acceptable to specify single port or port range with the help of '-' sign). To specify all the source ports, enter '0–65535';
- *Destination ports* – the list of destination ports, packets from which will follow the rule (it is acceptable to specify single port or port range with the help of '-' sign). To specify all the source ports, enter '0–65535'.


When ICMP is selected, the following settings will be available for editing:

- *Message type* – you can create the rule for the specific ICMP message type or for all ICMP message types.

Click the 'Apply' button to add a new rule. Click 'Cancel' to discard the changes. To delete a created rule, check the box next to the rule and click 'Remove'.

## 5.2.8 The 'Routes' submenu

You can set static routes in the Routes submenu.



Click the 'Add' button to add a new route. Fill the following fields:

Add Route

Name	<input type="text"/>
Destination	<input type="text"/>
Netmask	<input type="text"/>
Gateway	<input type="text"/>

- *Name* – route name;
- *Destination IP* – IP address of destination host or subnet that the route should be established to;
- *Netmask* – a subnet mask. A subnet mask for a host is set to 255.255.255.255 value, for a subnet – depending on its size;
- *Gateway* – gateway IP address that allows for the access to the *Destination IP*.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

## 5.2.9 The 'Dynamic DNS' submenu

✔ **The 'Dynamic DNS' submenu is available only in the 'Router' mode.**

In the 'Dynamic DNS' submenu, you can configure the corresponding service.

*Dynamic DNS (D-DNS)* provides information on DNS server update in real time or automatically, if necessary. It is used to assign a permanent domain name to a device (PC, router) with dynamic IP address.

Dynamic DNS is often used in local networks, where clients obtain IP addresses via DHCP, and then register their names on local DNS server.

The screenshot shows the 'Dynamic DNS' configuration page. At the top, there are tabs for 'Monitoring', 'Network', 'IPTV', and 'System'. Under 'Network', there are sub-tabs for 'Internet', 'LAN', 'MAC Management', 'Local DNS', 'NAT and Port Forwarding', 'Firewall', 'Routes', 'Dynamic DNS', and 'SNMP'. The 'Dynamic DNS' sub-tab is selected. The main content area is titled 'Dynamic DNS' and contains the following settings:

- Enable D-DNS:
- Server:
- User Name:
- Password:
- Domain Name 0:
- Domain Name 1:
- Domain Name 2:
- Domain Name 3:
- Domain Name 4:
- Domain Name 5:
- Domain Name 6:
- Domain Name 7:
- Domain Name 8:
- Domain Name 9:

At the bottom of the form, there are two buttons: 'Apply' (with a checkmark icon) and 'Cancel' (with an 'x' icon).

- *Enable D-DNS* – when selected, D-DNS service is enabled; the following settings will be available for editing:
  - *D-DNS provider name* – select one of the available providers;
  - *User name* – user name used to access D-DNS server account;
  - *Password* – password used to access D-DNS service account;
  - *Domain name (0..9)* – you can register up to 10 domain names (usually only one is required). The update of data on IP address of the device is implemented once in 60 seconds on a provider server.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

### 5.2.10 The 'SNMP' submenu

WB-2P-LR2 software allows monitoring of the device status and its sensors via SNMP. In The SNMP submenu, you can configure settings of SNMP agent. The device supports SNMPv1, SNMPv2c.

The screenshot shows the 'SNMP Settings' configuration page. The page has a navigation bar at the top with tabs for 'Monitoring', 'Network', 'IPTV', and 'System'. Under 'Network', there are sub-tabs for 'Internet', 'LAN', 'MAC Management', 'Local DNS', 'NAT and Port Forwarding', 'Firewall', 'Routes', 'Dynamic DNS', and 'SNMP'. The 'SNMP' tab is selected. The main content area is titled 'SNMP Settings' and contains the following fields:

- Enable SNMP:
- Read-only Community:
- Read-write Community:
- TrapSink:
- Trap2Sink:
- InformSink:
- System Name:
- Contact:
- Location:
- Trap Community:

At the bottom of the page, there are two buttons: 'Apply' (with a checkmark icon) and 'Cancel' (with an 'x' icon).

- *Enable SNMP* – when checked, SNMP is enabled;
- *roCommunity* – a password to read the parameters (by default: *public*);
- *rwCommunity* – a password to configure (write) parameters (by default: *private*);
- *TrapSink* – IP address or domain name of SNMPv1-trap message recipient in HOST [COMMUNITY [PORT]] format;
- *Trap2Sink* – IP address or domain name of SNMPv2-trap message recipient in HOST [COMMUNITY [PORT]] format;
- *InformSink* – IP address or domain name of Inform message recipient in HOST [COMMUNITY [PORT]] format;
- *Sys Name* – device name;
- *Sys Contact* – device vendor contact information;
- *Sys Location* – device location information;
- *Trap community* – password enclosed in traps (default value: trap).

The list of objects which are supported for reading and configuration via SNMP is given below:

- eltexLtd.1.164.1 – subscriber station parameters monitoring

where eltexLtd – 1.3.6.1.4.1.35265 is Eltex Enterprise identifier.

To apply a new configuration and save setting to non-volatile memory, click 'Apply'. Click 'Cancel' to discard the changes.

## 5.3 The 'IPTV' menu

✔ This menu is available only in the 'Router' mode.

### 5.3.1 The 'IPTV' submenu

You can configure IPTV service in IPTV settings menu.

- *Enable IPTV* – when checked, IPTV signals transmission via WAN interface (from provider network) to the devices connected to the LAN interface is enabled;
- *IGMP version* – IGMP version for IGMP messages sending from WAN interface (IPTV channel subscription activation/deactivation messages). Versions 2 and 3 are supported.

#### Renew subscription

- *Enable* – when option is enabled messages with active IPTV channel list are periodically sending from the WAN interface to higher server, that translating IPTV signals. Enabling of the function is necessary if a higher server disables IPTV channels translation in a certain period of time.
- *Renew Subscription Interval, s* – active IPTV channel list messages sending period, in seconds. Set the value of interval less than interval (timeout) of higher server signals translation disabling.

#### Fast leave mode

- *Enable* – when checked, the option for fast exit from the multicast group is enabled. The function is not recommended when more than one multicast traffic receiver is used.

#### HTTP Proxy Settings

- *Enable* – when checked HTTP proxy service is enabled. HTTP Proxy implements modification of UDP stream to HTTP stream using TCP (transmission control protocol), that allows to improve quality of transmitted image in case of poor communication channel quality in a local network. The function is useful when IPTV is watched via wireless Wi-Fi channel.
- *Port HTTP* – HTTP proxy port number that will be used for video streaming. Use this port to connect IPTV streams translated by the device.

For instance, if the device has the 192.168.0.1 address on the LAN interface, Proxy server's value is 1234 and you need to playback 227.50.50.100 channel broadcasted to UDP port 9000, set stream address for VLC programm in the form of: <http://@192.168.0.1:1234/udp/227.50.50.100:9000>.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

## 5.4 The 'System' menu

In the 'System' menu, you can configure system parameters: time, access via different protocols, change password, update software.

### 5.4.1 The 'Time' submenu

The configuration of time synchronization protocol (NTP) is implemented in the 'Time' submenu.

The screenshot displays the 'Time Settings' configuration interface. At the top, there are navigation tabs: Monitoring, Network, IPTV, and System (selected). Below these are sub-tabs: Time (selected), Access, Log, Passwords, Configuration Management, Firmware Upgrade, Reboot, Autoprovisioning, and Advanced. The main content area is titled 'Time Settings' and contains the following fields:

- Time Zone:** A dropdown menu set to 'Moscow, Russia'.
- Daylight Saving Time Enable:** A checked checkbox.
- DST Start:** Three dropdown menus for day, month, and year, followed by 'in' and another three dropdown menus for day, month, and year.
- at:** A dropdown menu for time (HH:MM).
- DST End:** Three dropdown menus for day, month, and year, followed by 'in' and another three dropdown menus for day, month, and year.
- at:** A dropdown menu for time (HH:MM).
- DST Offset (minutes):** A text input field containing '60'.
- Enable NTP:** A checked checkbox.
- NTP Server:** A dropdown menu set to 'pool.ntp.org'.

At the bottom of the form, there are two buttons: a blue 'Apply' button with a checkmark icon and a grey 'Cancel' button with an 'x' icon.

### Time settings

- *Time Zone* – allows to set the timezone according to the nearest city for your region from the list;
- *Daylight Saving Time Enable* – when selected, automatic daylight saving change will be performed automatically within the defined time period:
  - *DST Start* – day and time, when daylight saving time is starting;
  - *DST End* – day and time, when daylight saving time is ending;
  - *DST Offset (minutes)* – time period in minutes, on which time offset is performing.
- *Enable NTP* – check if it is needed to enable device system time synchronization from a certain NTP server;
- *NTP Server* – Time synchronization server IP address/domain name.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

## 5.4.2 The 'Access' submenu

In the 'Access' submenu, you can configure access to the device via web interface, Telnet and SSH.

The screenshot shows the 'Access' submenu in the System configuration page. The page is titled 'System' and has a sub-menu 'Access'. The 'Access Ports' section contains four input fields: HTTP Port (80), HTTPS Port (443), Telnet Port (23), and SSH Port (22). The 'Access to Internet Service' section has three sub-sections: Web, Telnet, and SSH. Each sub-section has two checkboxes: WAN and LAN. For Web, both WAN and LAN have checkboxes for HTTP and HTTPS. For Telnet, both WAN and LAN have checkboxes. For SSH, both WAN and LAN have checkboxes. At the bottom, there are 'Apply' and 'Cancel' buttons.

### Access Ports

In this section you can configure TCP ports for the access to the device via HTTP, HTTPS, Telnet, and SSH:

- *HTTP port* – number of the port for access to the device web interface via *HTTP*, default value is 80;
- *HTTPS port* – number of the port for access to the device web interface via *HTTPS* (*HTTP Secure* – secure connection), default value is 443;
- *Telnet Port* – number of port for access to web interface via *Telnet* (default is 23);
- *SSH Port* – number of port for access to web interface via *SSH* (default is 22).

You can use *Telnet* and *SSH* protocols in order to access the command line (Linux console).

### Access to Internet service

This section allows or denies access to the device with separate rules for local and external networks (router mode). For this you need to set the following permissions:

#### **Web:**

- *HTTP* – when selected, the WAN port connection to the device web configurator is enabled via *HTTP* (insecure connection);
- *HTTPS* – when selected, the WAN port connection to the device web configurator is enabled via *HTTPS* (insecure connection).

#### **Telnet:**

*Telnet* is a protocol that allows you to establish mechanisms for remote control of the devices. It allows you to connect to the device via network for configuration and management purposes.

To enable the device access via *Telnet* protocol, select the corresponding checkbox.

**SSH:**

SSH – secure protocol of device remote control. As opposed to Telnet, SSH encrypts all traffic being transferred including passwords;

To enable the device access via SSH protocol, select the corresponding checkbox.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

## 5.4.3 The 'Log' submenu

The 'Log' submenu is designed to configure the output of various kinds of debugging messages of the system in order to detect the causes of problems in the operation of the device. Debug information may be provided by the following device firmware modules:

- Networkd Log – deals with the device configuration according to the configuration file;
- Configd Log – deals with the configuration file operations (config file reads and writes from various sources) and the device monitoring data collection.

The screenshot shows the 'Log' submenu configuration interface. The interface is divided into three sections: Networkd Log, Configd Log, and Syslog Settings. Each section has a 'Log Output' dropdown menu set to 'Disabled' and four checkboxes for 'Error', 'Warning', 'Debug', and 'Info'. The Syslog Settings section includes an 'Enable' checkbox, a 'Mode' dropdown set to 'Server', and input fields for 'Syslog Server Address' (syslog.server), 'Syslog Server Port' (514), and 'File Size, KiB' (5000). At the bottom, there are 'Apply' and 'Cancel' buttons.

Networkd Log

- *Log Output* – log messages output direction:
  - *Disabled* – the output is disabled;
  - *Syslog* – messages are output to the remote server or local file via syslog protocol (protocol configuration is carried out below);

- *Console* – messages are output to device console (connection via COM port adapter is needed);
- *Telnet* – messages are output to the telnet session; create telnet protocol connection first.

Select types of messages to be output in Networkd Log:

- *Error* – check if it is needed to output 'Error' type messages;
- *Warning* – check if it is needed to output 'Warning' type messages;
- *Debug* – check to collect debug messages;
- *Info* – check to collect information messages.

#### Configd Log

- *Log Output* – log messages output direction:
  - *Disabled* – the output is disabled;
  - *Syslog* – messages are output to the remote server or local file via syslog protocol (protocol configuration is carried out below);
  - *Console* – messages are output to device console (connection via COM port adapter is needed);
  - *Telnet* – messages are output to the telnet session; create telnet protocol connection first.

Select types of messages to be output in Configd Log:

- *Error* – check if it is needed to output 'Error' type messages;
- *Warning* – check if it is needed to output 'Warning' type messages;
- *Debug* – check to collect debug messages;
- *Info* – check to collect information messages.

#### Syslog settings

If there is at least a single log (Networkd Log or Configd Log) configured for Syslog output, you should enable Syslog agent that will intercept debug messages and send them to a remote server or save them to a local file in Syslog format.

- *Enable* – when checked syslog agent is running;
- *Mode* – Syslog agent operation mode:
  - *Server* – log information is sending to remote Syslog server;
  - *Local file* – log information is saving to local file;
  - *Server and file* – log information is sending to remote Syslog server and saving to local file.

According to Syslog agent mode, the following settings might be available:

- *Syslog server address* – Syslog server IP address or domain name (required for 'Server', 'Server and file' modes);
- *Syslog server port* – port for Syslog server incoming messages (default value is 514; required for 'Server', 'Server and file' modes);
- *File name* – name of the file to store log in Syslog format (required for 'Local file', 'Server and file' modes);
- *File size, KB* – maximum log file size (required for 'Local file', 'Server and file' modes).

#### 5.4.4 The 'Passwords' submenu

In the 'Passwords' submenu you can define passwords for administrator and viewer access.

The set passwords are used for access to the device via web interface, Telnet and SSH.

When logging in via web interface administrator (default password: **password**) has the full access to the device: read/write any settings, full device status monitoring. A viewer (password by default: **viewer**) has rights to view configuration and device monitoring data. Viewer is not permitted to change settings.

- ✔ **Administrator login: admin**  
**Viewer login: viewer**

The screenshot shows the 'System' menu with 'Passwords' selected. The 'Administrator Password' section contains a 'Password' field with a visibility toggle and a 'Confirm' field, followed by an 'Apply' button. The 'Viewer Password' section also contains a 'Password' field with a visibility toggle and a 'Confirm' field, followed by an 'Apply' button.


- *Administrator Password* – type administrator password and confirmation in corresponding fields;
- *Viewer password* – enter user password in the corresponding field and confirm it.

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

### 5.4.5 The 'Configuration management' submenu

In the 'Configuration management' submenu you can save and update the current configuration.

#### Backup Configuration



To save the current device configuration to a local PC, click 'Download' button.

#### Restore Configuration

- *Upload configuration archive to the device* – upload of configuration file saved on local computer. To update the device configuration click the 'Choose file' button, specify a file (in .tar.gz format) and click the 'Upload' button. Uploaded configuration will be applied automatically and does not require device reboot.

✔ **Note that all the passwords of configuration are encrypted with a key depending on device MAC address. Before loading a configuration from one device to another, you should change all passwords in configuration file.**

To change the passwords open the configuration file in text editor and change passwords. Then save the changes in configuration archive. The example of password changing is shown below:

```

Passwords:
AdminPassword: "encrypted:7C607178736B7465"
ViewerPassword: "encrypted:7A68677C6176"

```

changes to

```

Passwords:
AdminPassword: "password"
ViewerPassword: "password"

```

#### Reset to Default Configuration

To reset all the settings to default values, click the 'Reset' button.

### 5.4.6 The 'Firmware Upgrade' submenu

The 'Firmware Upgrade' submenu is dedicated to update firmware version of the device.

WB-2P-LR2 firmware upgrade:

The screenshot shows the 'Firmware Upgrade' page with the following elements:

- Navigation tabs: Monitoring, Network, IPTV, System (selected).
- Submenu: Time, Access, Log, Passwords, Configuration Management, Firmware Upgrade (selected), Reboot, Autoprovisioning, Advanced.
- Section: Firmware Upgrade
- Active Version: 2.3.0.213 with a 'Check for Update' button.
- Backup Version: 2.2.0.261 with a 'Set Active' button.
- Link: Firmware upgrade is also available at <http://eltex-co.ru/support/downloads/>
- Firmware Image field with a 'Browse...' button.
- 'Upload File' button.

- *Active Version* – installed firmware version, which is operating at the moment;
- *Backup version* – installed firmware version which can be used in case of problems with the current active firmware version;
- *Check for update* – click this button to check the availability of the latest firmware version. With this function, you can quickly check the latest firmware version and update the firmware, if necessary;
- *Make active* – a button that allows you to make a backup version of the firmware active, this will require a reboot of the device. The active firmware version will not be set as a backup.

✔ **Firmware update check function requires access to the Internet.**


You can upgrade the device firmware manually by downloading the firmware file from the web site <http://eltex-co.com/support/downloads/> and saving it on the computer. To do this, click the 'Select file' button in the *Software update file* field and specify the path to the file in .tar.gz format.

To start the upgrade process, click the 'Upload file' button. The process may take several minutes (its current status will be shown on the page). The device will be automatically rebooted when the upgrade is completed.

⚠ **Do not switch off or reboot the device during the firmware update.**

### 5.4.7 The 'Reboot' submenu

In the 'Reboot' submenu you can reboot the device.



Click the 'Reboot' button to reboot the device. Device reboot process takes approximately 1 minute to complete.

### 5.4.8 The 'Autoprovisioning' submenu

In the 'Autoprovisioning' submenu you can configure DHCP-based autoprovisioning algorithm and subscriber device automatic configuration protocol TR-069.

 A screenshot of a web interface showing the 'Autoprovisioning' submenu. The 'System' menu is selected, and 'Autoprovisioning' is highlighted. The page title is 'DHCP-based Autoprovisioning'. The form contains the following fields:
 

- Provisioning Mode: Configuration and Firmware (dropdown)
- Parameters Priority from: DHCP options (dropdown)
- Configuration File: (text input)
- Configuration Update Interval, s: 300 (text input)
- Firmware File: (text input)
- Firmware Upgrade Interval, s: 3600 (text input)

 Below this is the 'TR-069 Autoconfiguration' section:
 

- Common**
  - Enable TR-069 Client:
  - ACS Server Address: http://update.local:9595/ (text input)
  - Enable Periodic Inform:
  - Periodic Inform Interval, s: 60 (text input)
- ACS Connection Request**
  - User Name: acs (text input)
  - Password: acsacs (text input)
- Client Connection Request**
  - User Name: admin (text input)
  - Password: admin (text input)
- NAT Settings**
  - NAT Mode: Off (dropdown)

 At the bottom, there are 'Apply' and 'Cancel' buttons.

#### DHCP-based Autoprovisioning:

- *Provisioning Mode* – select a mode for automatic device update. The followings are available:
  - *Disabled* – automatic update of configuration and firmware is disabled;
  - *Configuration and Firmware* – periodical configuration and firmware update is permitted;
  - *Configuration only* – only periodical update of configuration is permitted;

- *Firmware only* – only periodical update of firmware is permitted.
- *Parameters Priority from* – this parameter determines where you need to get the names and location of configuration files and firmware:
  - *Static settings* – paths to configuration and firmware files are defined by the 'Configuration file' and 'Firmware file' settings correspondingly; more detailed information on the algorithm see in section [DHCP-based autoupdate algorithm](#);
  - *DHCP options* – paths to configuration and firmware files are defined by the DHCP Option 43, 66, and 67 (to do this, you should select DHCP for the Internet service); more detailed information on the algorithm see in section [DHCP-based autoupdate algorithm](#);
- *Configuration File* – full path to configuration file – set in URL format (there is an opportunity to load configuration files via TFTP):

tftp://<server address>/<full path to cfg file>

where < server address > – TFTP server address (domain name or IPv4),

< full path to cfg file > – full path to configuration file on the server;

- *Configuration Update interval, s* – the time interval in seconds, after which the device configuration is periodically updated. If 0 is set, update of the device will be implemented once, right after reloading of the device;
- *Firmware File* – the full path to the firmware file is specified in the URL format (at the moment it is possible to download the software file using TFTP):

tftp://<server address>/<full path to firmware file>

where < server address > – TFTP server address (domain name or IPv4),

< full path to firmware file > – full path to configuration file on the server.

- *Firmware Upgrade Interval, s* – a time interval. The firmware update is implemented according to this period. If 0 is set, update of the device will be implemented once, right after reloading of the device.

More detailed information on the algorithm see in section [DHCP-based autoupdate algorithm](#).

### Autoconfiguration via TR-069:

#### Common:

- *Enable TR-069 Client* – when checked, the operation of embedded TR-069 client is enabled, otherwise it is prohibited.
- *ACS Server Address* – autoconfiguration server address. The address should be entered in the following formats `http://<address>:<port>` or `https://<address>:<port>` (<address> – IP address or domain name of ACS server, <port> – ACS server port, the default port is 9595). The second format is to use the secure protocol – HTTPS for exchanging data with ACS server.
- *Enable Periodic Inform* – when checked, internal TR-069 client performs periodic ACS server polling with an interval equal to the 'Periodic Inform Interval' in seconds. The poll aim is to detect device configuration changes.

#### ACS Connection Request:

- *User Name, Password* – user name and password for client to access ACS server.

#### Client Connection Request:

- *User Name, Password* – user name and password for ACS server to access TR-069 client.

#### NAT Settings:

If there is modification of network addresses between client and ACS server (NAT – network address translation), ACS server might not have the opportunity to establish connection with the client if certain technologies are not used to avoid it. The technologies help the client to define so called public address (NAT addresses – an address of external gateway, behind which the client is located). When the public address is defined, the client inform the server. Then, the server uses the public address (not the local) to establish connection with the client.

- *NAT Mode* – determines how the client should receive information about their public address. The following modes are available:
  - *STUN* – use STUN protocol for public address identification;
  - *Manual* – manual mode, when public address is explicit in configuration; in this mode, you should add a forwarding rule on a device that acts as a NAT for TCP port used by TR-069 client;
  - *Off* – NAT will not be used—this mode is recommended only when the device is directly connected to ACS server without network address translation. In this case, public address coincides with local one.

When *STUN* mode is selected you should configure the following settings:

- *STUN server address* – STUN server IP address or domain name;
- *STUN Server Port* – UDP port of STUN server (the value by default is 3478);
- *Minimum keep alive period, s* and *Maximum keep alive period, s* – define the time interval in seconds for periodic transmission of messages to STUN server for public address discovery and modification.

If *Manual* mode is selected, the client's public address is set manually via the *NAT Address* parameter (the address must be entered in IPv4 format).

Through TR-069, you can implement main configuration of the device, firmware update and reading the data on the device (firmware version, model, serial number, etc.), uploading/downloading of configuration file, remote reboot (TR-069, TR-098 specifications are supported).

To apply a new configuration and store settings into the non-volatile memory, click the '*Apply*' button. To discard changes click the '*Cancel*' button.

### 5.4.9 The 'Advanced' submenu

In the 'Advanced' submenu you can set reserved VLAN ID and enable UPnP.

The screenshot shows a configuration window for UPnP. It is divided into three main sections:

- UPnP:** Contains a checkbox labeled "Enable UPnP" which is checked.
- Reserved VLAN ID:** Contains two input fields: "Start VLAN ID" with the value "1" and "End VLAN ID" with the value "6".
- Local management via Ethernet:** Contains a checkbox labeled "Enabled" which is checked, and two input fields: "Management IP-address" with the value "192.0.3.1" and "Netmask" with the value "255.255.255.0".

At the bottom of the window, there are two buttons: a blue "Apply" button and a grey "Cancel" button.

#### UPnP

UPnP is used by some applications (e.g. DC clients such as FlylinkDC++) to create forwarding rules for TCP/UDP ports used by these applications on a higher router. It is recommended to enable UPnP for operation of file exchange services on a network.

- *Enable UPnP* – when checked, UPnP is enabled, otherwise – disabled.

#### Reserved VLAN ID

Reserved VLAN ID – the list of service VLANs, which are used for solving intrasystem tasks.

- *Start VLAN ID* – starting VLAN ID value in the reserved range;
- *End VLAN ID* – ending VLAN ID value in the reserved range.


#### Local management via Ethernet

Local management via Ethernet – enables device accessibility without tag via Ethernet.

- *Management IP-address* – IP address of the Ethernet interface in local network (by default 192.0.3.1);
- *Netmask* – subnet mask.


## 6 Configuration example

1. Connect PC to LAN port of injector;
2. Enter IP address of the device to URL bar of a browser (192.168.1.1 by default, if address was not obtain via DHCP); When connection is established successfully, the window with Login and password fields will be displayed. Fill the fields and click 'Log in'. (By default, login: **admin**, password: **password**).



Login:  
  
 Password:

If the window is not displayed, make sure that the PC and the device are in the same network.



Monitoring **Network** System  
 Internet MAC Management Firewall Routes SNMP

Common Settings

Hostname

WAN

Device Mode

Connection Settings

SSID

802.11 Mode

Channel Bandwidth

Security Mode

Tx Power (dBm)

Short Guard Interval

Fixed Center Frequency

Limit Channels

Fixed Transmit Rate

Maximal Transmit Rate

ACK Timeout

Network Mode

Priority

Protocol

VLAN Trunk Mode

Alternative Vendor ID (option 80)

Vendor ID (option 80)

Primary DNS Server

Secondary DNS Server

Tx Broadcast Rate Limit (packets/sec)

Traffic Shaper

Implement configuration on the Internet tab. In Network Mode field, select the required mode: Bridge or Router. If static settings are used for connection to a provider network, choose 'Static' value in 'Protocol' field and fill the fields: 'IP address', 'Netmask', 'Default gateway', 'Primary DNS Server', 'Secondary DNS Server' – the values are given by service provider.

Configure connection to a base station. Specify SSID of the wireless network, you want to connect to, in the corresponding field. Select security mode through which authentication in the selected wireless network is implemented and specify the key if using an encrypted network. After clicking on the 'Apply' button, the subscriber station will search for the specified SSID on the air and, upon detection, will attempt to connect to the base station with the specified parameters. If the parameters are specified correctly and the signal level is sufficient, a successful connection will occur.

## 7 Limiting the number of MAC addresses learned (mac-learning limit)

To enable the functionality of limiting the number of learned MAC addresses, you must connect to the device via telnet/ssh and set a few setup commands.

### Limiting the number of MAC addresses learned

```
root@WB-2P-LR2:~$ setconf Internet.Network EnableMacLearningLimit 1 Enable limiting the number of MAC addresses learned. To disable enter 0.
```

```
root@WB-2P-LR2:~$ setconf Internet.Network MacLearningLimit 100 Global limiting the number of MAC addresses (Wi-Fi+Ethernet). Possible values: 1-2048. Default – 2048, it is not recommended to change this value.
```

```
root@WB-2P-LR2:~$ setconf Internet.Network WifiMacLearningLimit 100 Limiting the number of MAC addresses on the Wi-Fi side. Possible values: 1-2048.
```

```
root@WB-2P-LR2:~$ setconf Internet.Network EthMacLearningLimit 100 Limiting the number of MAC addresses on the Ethernet side. Possible values: 1-2048.
```

```
root@WB-2P-LR2:~$ setconf Internet.Network DropUnknownUcastSrc 1 Enable the prohibition of transferring traffic from devices whose MAC addresses have not been learned due to exceeding any limit of learned MAC addresses. To disable enter 0.
```

```
root@WB-2P-LR2:~$ setconf Internet.Network DropUnknownUcast 1 Enable the prohibition of traffic transfer to unexplored MAC-addresses (unicast only). To disable enter 0.
```

## 8 Spectrum Analyzer

To use the embedded spectrum analyzer on the WB-2P-LR2, you need to login to the device via telnet or ssh. Enter the **spectrum-analyzer** command to run it. The analysis time for all the radio channels in the range is approximately 5 minutes.

- ✔ **Please note that all clients will disconnect from the base station during spectrum analyzer operation. The subscriber stations will be connected again only when the spectrum analyzer finishes its work.**

The result can be obtained using the **spectrum-analyzer-result** command. Information on the loading of each channel (in percent) will be displayed in the console:

```

root@WB-2P-LR2:~$ spectrum-analyzer
Spectrum analyzer scanning in progress
root@WB-2P-LR2:~$
root@WB-2P-LR2:~$ spectrum-analyzer-result
=====start dump config=====
node: Monitoring.Network.SpectrumAnalyzer
  name: 1, value: 13
  name: 2, value: 21
  name: 3, value: 1
  name: 4, value: 3
  name: 5, value: 20
  name: 6, value: 76
  name: 7, value: 9
  name: 8, value: 3
  name: 9, value: 3
  name: 10, value: 10
  name: 11, value: 28
  name: 12, value: 22
  name: 13, value: 10
=====end dump config=====

```

## 9 Automatic DHCP-based update algorithm

Automatic device update procedure algorithm is determined by the '*Parameters priority from*' parameter value.

1. If the '*Static settings*' value is selected, then the full path (including the access protocol and server address) to the configuration files and firmware is determined from the '*Configuration file*' and '*Firmware file*'. Full path should be specified in URL format:  
 <protocol>://<server address>/<path to file>, where:
  - <protocol> – protocol used for downloading corresponding files from the server (TFTP is supported);
  - <server address> – address of the server with a file to be downloaded (domain name or IPv4);
  - <path to file> – path to file on the server.

You can use the following macro in URL (reserved words substituted with the specific values):

- $\$MA$  – MAC address – instead of this macro, the device inserts its own MAC address in the file URL;
- $\$SN$  – Serial number – instead of this macro, the device inserts its own serial number in the file URL;
- $\$PN$  – Product name – the macro is substituted with device's model name in file URL (e.g., WB-2P-LR2).

For MAC address, serial number and model name, see 'Device' section on the monitoring page.

URL examples:

[tftp://download.server.loc/firmware.file](http://download.server.loc/firmware.file), <http://192.168.25.34/configs/WB-2P-LR2//my.cfg> ,

[tftp://server.tftp/\\$PN/config/\\$SN.cfg](http://server.tftp/$PN/config/$SN.cfg), [http://server.http/\\$PN/firmware/\\$MA.frm](http://server.http/$PN/firmware/$MA.frm) , etc.

Some URL parameters might be omitted. For example, configuration file can be specified in the following format:

<http://192.168.18.6>

or

config\_wb.cfg

If the system is unable to extract the necessary file downloading parameters (protocol, server address or path to file on server) from configuration file or firmware file URL, it will attempt to extract an unknown parameter from DHCP Option 43 (Vendor specific info) or 66 (TFTP server) and 67 (Boot file name), when address obtaining via DHCP is enabled for the Internet service (DHCP option format and analysis will be provided below). If the system is unable to extract missing parameter from DHCP options, default value will be used:

- For protocol: tftp;
- For a server address: update.local;
- For a configuration file name WB-2P-LR2.cfg;
- For a firmware file name WB-2P-LR2.fw.

Thus, if the '*Configuration File*' and '*Software File*' fields are left empty, options 43 or 66, 67 with the location of these files will not be received via DHCP – the URL of the configuration file will look like:

<tftp://update.local/WB-2P-LR2.cfg> ,

and the firmware file URL:

<tftp://update.local/WB-2P-LR2.fw> .

2. If the 'DHCP options' value is selected, configuration file and firmware file URLs will be extracted from DHCP Option 43 (Vendor specific info) or 66 (TFTP server) and 67 (Boot file name), thus, address obtaining via DHCP should be enabled for the Internet service (DHCP option format and analysis will be provided below). If URL parameters are not provided by DHCP options, default parameters values will be used:

- For protocol: tftp;
- For a server address: update.local;
- For a configuration file name WB-2P-LR2.cfg;
- For a firmware file name WB-2P-LR2.fw.

### Option 43 format (Vendor specific info)

1|<acs\_url>|2|<pcode>|3|<username>|4|<password>|5|<server\_url>|6|<config.file>|7|<firmware.file>|8|<vlan\_tag>, where:

- 1 – TR-069 autoconfiguration server address code;
- 2 – 'Provisioning code' parameter specification code.
- 3 – code of the username for TR-069 server authorization;
- 4 – code of the password for TR-069 server authorization;
- 5 – server address code; server address is specified in URL format: <tftp://address> or <http://address> . The first version represents TFTP server address, the second version – HTTP server address;
- 6 – configuration file name code;
- 7 – firmware file name code;
- 8 – a code of VLAN tag for management;
- '|' – mandatory separator used between codes and suboption values.

### Algorithm of identification for configuration file and firmware file URL parameters from DHCP Options 43 and 66, 67.

1. DHCP exchange initialization  
Device initializes DHCP exchange after the startup.
2. Option 43 analysis  
When Option 43 has been received, suboption 8 is analyzed (vlan\_tag):

- if there is a suboption and it is different from current VLAN tag, DHCP exchange is initiated in new VLAN;
- suboption is absent or present and does not differ from the current VLAN tag: suboptions with codes 5, 6, and 7 are analyzed to determine the server address and the names of the configuration files and software.

### 3. Option 66 analysis.

If Option 43 is not received from DHCP server or it is received but the system fails to extract the server address, Option 66 will be searched. If the system fails to obtain the firmware file name, Option 67 will be searched. They are used for TFTP server address and the firmware file path extraction respectively. Then, configuration and firmware files will be downloaded from Option 66 address via TFTP.

#### **Special aspects of configuration updates**

Configuration file should be in **.tar.gz** format (this format is used when configuration is saved from the web interface in the 'System' – 'Configuration management' tab). Configuration downloaded from the server will be applied automatically and does not require device reboot.

#### **Special aspects of firmware updates**

The firmware file must be in the **.tar.gz** format. When the firmware file is loaded, the device unpacks it and checks its version (using 'version' file in tar.gz archive).

If the current firmware version matches the version of the file obtained via DHCP, firmware will not be updated. Update is performed only when firmware versions are mismatched. When the firmware image is written into the device flash memory, the Power indicator will flash green, orange and red in succession.

**⚠ Do not power off or reboot the device, when the firmware image is written into the flash memory. These actions will interrupt the firmware update that will lead to the device boot partition corruption. The device will become inoperable. To restore the device operation, use the instruction provided in [System recovering after firmware update failure](#).**

## 10 System recovering after firmware update failure

If while the firmware update (through the web interface or through autoupdate mechanism based on DHCP) a failure occurred (e.g. due to power cutoff) and the device does not operate (the 'Power' indicator is constantly solid red), use the following algorithm to recover the device:

- Unpack the archive with firmware file;
- Connect PC to the device port. Set the following subnet mask on the network interface: 192.168.1.0/24;
- Run the TFTP client on the PC (for Windows, it is recommended to use the Tftpd32), specify 192.168.1.6 as the remote host address, and select the linux.bin file from the unpacked software archive for transfer;
- Run the command to send a file to a remote host (the **Put** command). The process of file transmission will be launched;
- If the transmission has started, please, wait for finishing. The device will write the firmware to its memory and launch the system automatically. The time of writing takes approximately 8 minutes. If the process is completed successfully, 'Power' indicator will be green or orange. The configuration of the device before failure is saved. If you can not connect the device, reset it to factory settings;
- If the process has not started, make sure that the network settings of PC are correct and try again. If it does not work, sent the device to maintenance service or proceed recovery using the connection via COM port through a special adapter (if available);

## 11 Appendix A. Launch user script when starting the system

Sometimes you need the device to implement certain actions when starting, which cannot be implemented through settings in configuration file. In this case you can configure a user script through a configuration file that will be launched when the system starting. You can set any needed commands sequence.

For user script launching, there is a settings section in the configuration file `cfg.yaml`:

```
UserScript:
Enable: "0"
URL: ""
```

The *'Enable'* option allows (if the value is 1) or denies (if the value is 0) the script launch, the path to which is specified in the *URL* parameter.

The userscript might be located on remote server as well as on the device. The script is loaded via HTTP or TFTP from remote server. Examples of configuration files for user script launching using different sources are given below:

### 1. Launch from HTTP server

To launch a script from HTTP server, enter the entire path to the file in HTTP-URL format to *URL* parameter:

```
URL: " http://192.168.0.250/user-script/script.sh "
```

In this case, after the device started, file `script.sh`, which is kept in the catalogue having `192.168.0.250` address, will be automatically loaded via HTTP from the defined server. Then it will be launched.

### 2. Launch from TFTP server

To launch a script from TFTP server, enter the entire path to the file in TFTP-URL format to *URL* parameter:

```
URL: " tftp://192.168.0.250/user-script/script.sh "
```

In this case, after the device started, file `script.sh`, which is kept in the catalogue having `192.168.0.250` address, will be automatically loaded via TFTP from the defined server. Then it will be launched.

### 3. Local script launch

Due to the peculiar properties of the file system, a local script should be stored in `/etc/config` catalogue as the content of the catalogue is saved after device reload. The script in the `/etc/config` directory can be created either using the vi editor, or download it from an external TFTP server (using the `tftp -gl sh <TFTP-server address>` command). After creating a script, you should set rights for launching using the following command:

```
chmod 777 /etc/config/user.sh
```


In configuration file, URL for local script launching should be set as follows:

```
URL: " File://etc/config/user.sh "
```


A user script should start from the `#!/bin/sh` directive.

## 12 Application B. Antenna patterns

**The pattern of vertically polarized antenna:**



**The pattern of horizontally polarized antenna:**



## 13 The list of changes

Document version	Issue date	Revisions
Version 1.4	30.01.2022	Synchronization with firmware version 2.6.0  Changed: <ul style="list-style-type: none"><li>• 5.4.9 The 'Advanced' submenu</li></ul>
Version 1.3	11.10.2021	Synchronization with firmware version 2.5.0  Added: <ul style="list-style-type: none"><li>• 3.3 Recommendations for lightning protection</li><li>• 7 Limiting the number of MAC addresses learned (mac-learning limit)</li></ul> Changed: <ul style="list-style-type: none"><li>• 5.2.1 The 'Internet' submenu</li></ul>
Version 1.2	22.12.2020	Synchronization with firmware version 2.4.1
Version 1.1	07.04.2020	Synchronization with firmware version 2.4.0  Added: 4.4 Test changes mode  Changes in sections: 5.2.1 The 'Network/Internet' menu
Version 1.0	06.11.2019	First issue
<b>Firmware version</b>		2.6.0

## TECHNICAL SUPPORT

For technical assistance in issues related to handling Eltex Ltd. equipment, please, address to Service Center of the company:

<http://www.eltex-co.com/support>

You are welcome to visit Eltex official website to get the relevant technical documentation and software, to use our knowledge base or consult a Service Center Specialist in our technical forum.

<http://www.eltex-co.com/>

<http://www.eltex-co.com/support/downloads/>